

libATA Developer's Guide

Jeff Garzik

libATA Developer's Guide

by Jeff Garzik

Copyright © 2003-2006 Jeff Garzik

The contents of this file are subject to the Open Software License version 1.1 that can be found at <http://www.opensource.org/licenses/osl-1.1.txt> and is included herein by reference.

Alternatively, the contents of this file may be used under the terms of the GNU General Public License version 2 (the "GPL") as distributed in the kernel source COPYING file, in which case the provisions of the GPL are applicable instead of the above. If you wish to allow the use of your version of this file only under the terms of the GPL and not to allow others to use your version of this file under the OSL, indicate your decision by deleting the provisions above and replace them with the notice and other provisions required by the GPL. If you do not delete the provisions above, a recipient may use your version of this file under either the OSL or the GPL.

Table of Contents

1. Introduction.....	1
2. libata Driver API.....	3
2.1. struct ata_port_operations	3
2.1.1. Disable ATA port	3
2.1.2. Post-IDENTIFY device configuration	3
2.1.3. Set PIO/DMA mode.....	3
2.1.4. Taskfile read/write.....	4
2.1.5. PIO data read/write	4
2.1.6. ATA command execute	4
2.1.7. Per-cmd ATAPI DMA capabilities filter	5
2.1.8. Read specific ATA shadow registers	5
2.1.9. Select ATA device on bus.....	5
2.1.10. Private tuning method	6
2.1.11. Control PCI IDE BMDMA engine	6
2.1.12. High-level taskfile hooks	7
2.1.13. Exception and probe handling (EH)	7
2.1.14. Hardware interrupt handling	8
2.1.15. SATA phy read/write.....	9
2.1.16. Init and shutdown.....	9
3. Error handling	11
3.1. Origins of commands.....	11
3.2. How commands are issued.....	11
3.3. How commands are processed.....	12
3.4. How commands are completed	12
3.5. ata_scsi_error()	13
3.6. Problems with the current EH.....	14
4. libata Library	17
ataapi_cmd_type	17
ata_tf_to_fis.....	18
ata_tf_from_fis	19
ata_pack_xfermask	20
ata_unpack_xfermask	21
ata_xfer_mask2mode	22
ata_xfer_mode2mask	23
ata_xfer_mode2shift	24
ata_mode_string	25
ata_dev_classify	26
ata_id_string.....	27
ata_id_c_string.....	28
ata_id_xfermask.....	29

ata_pio_need_iordy.....	30
ata_do_dev_read_id	31
ata_cable_40wire	32
ata_cable_80wire	33
ata_cable_unknown.....	34
ata_cable_ignore	35
ata_cable_sata	36
ata_port_probe	36
ata_dev_pair	37
ata_port_disable	38
sata_set_spd	39
ata_timing_cycle2mode	40
ata_do_set_mode.....	41
ata_wait_after_reset	42
sata_link_debounce.....	44
sata_link_resume.....	45
ata_std_prereset.....	46
sata_link_hardreset	47
sata_std_hardreset.....	49
ata_std_postreset.....	50
ata_std_qc_defer	51
ata_sg_init.....	52
ata_qc_complete	53
ata_qc_complete_multiple	54
sata_scr_valid.....	55
sata_scr_read.....	56
sata_scr_write	57
sata_scr_write_flush.....	59
ata_link_online.....	60
ata_link_offline	61
ata_host_suspend	62
ata_host_resume.....	63
ata_port_start.....	64
ata_host_alloc	65
ata_host_alloc_pinfo	66
ata_slave_link_init	68
ata_host_start	69
ata_host_init.....	70
ata_host_register	71
ata_host_activate.....	72
ata_host_detach.....	74
ata_pci_remove_one	75
ata_wait_register	76

5. libata Core Internals.....	79
ata_dev_phys_link	79
ata_force_cbl.....	80
ata_force_link_limits	81
ata_force_xfermask.....	82
ata_force_horkage.....	83
ata_rwcmd_protocol	83
ata_tf_read_block.....	84
ata_build_rw_tf.....	85
ata_dev_enable_pm.....	87
ata_dev_disable_pm.....	88
ata_read_native_max_address	89
ata_set_max_sectors	90
ata_hpa_resize.....	91
ata_dump_id.....	92
ata_pio_queue_task.....	93
ata_port_flush_task	94
ata_exec_internal_sg.....	95
ata_exec_internal	97
ata_do_simple_cmd	98
ata_pio_mask_no_iordy	99
ata_dev_read_id	100
ata_dev_configure	102
ata_bus_probe	103
sata_print_link_status	104
sata_down_spd_limit	105
sata_set_spd_needed.....	105
ata_down_xfermask_limit.....	107
ata_wait_ready	108
ata_dev_same_device.....	109
ata_dev_reread_id.....	110
ata_dev_revalidate.....	111
ata_is_40wire	113
cable_is_40wire	113
ata_dev_xfermask	114
ata_dev_set_xfermode	115
ata_dev_set_feature.....	116
ata_dev_init_params	117
ata_sg_clean.....	119
atapi_check_dma.....	119
ata_sg_setup.....	120
swap_buf_le16	121
ata_qc_new	122

ata_qc_new_init	123
ata_qc_free	124
ata_qc_issue	125
ata_phys_link_online	126
ata_phys_link_offline	127
ata_dev_init	128
ata_link_init	129
sata_link_init_spd	130
ata_port_alloc	131
ata_finalize_port_ops	132
ata_port_detach	133
6. libata SCSI translation/emulation	135
ata_std_bios_param	135
ata_scsi_slave_config	136
ata_scsi_slave_destroy	137
ata_scsi_change_queue_depth	138
ata_scsi_queuecmd	139
ata_scsi_simulate	140
ata_sas_port_alloc	141
ata_sas_port_start	142
ata_sas_port_stop	143
ata_sas_port_init	144
ata_sas_port_destroy	145
ata_sas_slave_configure	146
ata_sas_queuecmd	147
ata_get_identity	147
ata_cmd_ioctl	148
ata_task_ioctl	149
ata_scsi_qc_new	150
ata_dump_status	152
ata_to_sense_error	153
ata_gen_ata_sense	154
atapi_drain_needed	155
ata_scsi_start_stop_xlat	156
ata_scsi_flush_xlat	157
scsi_6_lba_len	158
scsi_10_lba_len	159
scsi_16_lba_len	160
ata_scsi_verify_xlat	161
ata_scsi_rw_xlat	163
ata_scsi_translate	164
ata_scsi_rbuf_get	165
ata_scsi_rbuf_put	166

ata_scsi_rbuf_fill.....	167
ata_scsiop_inq_std.....	168
ata_scsiop_inq_00.....	169
ata_scsiop_inq_80.....	170
ata_scsiop_inq_83.....	171
ata_scsiop_inq_89.....	173
ata_scsiop_noop.....	174
ata_msense_caching.....	174
ata_msense_ctl_mode.....	175
ata_msense_rw_recovery.....	176
ata_scsiop_mode_sense.....	177
ata_scsiop_read_cap.....	178
ata_scsiop_report_luns.....	179
atapi_xlat.....	180
ata_scsi_find_dev.....	181
ata_scsi_pass_thru.....	182
ata_get_xlat_func.....	183
ata_scsi_dump_cdb.....	184
ata_scsi_offline_dev.....	185
ata_scsi_remove_dev.....	186
ata_scsi_media_change_notify.....	187
ata_scsi_hotplug.....	188
ata_scsi_user_scan.....	189
ata_scsi_dev_rescan.....	190
7. ATA errors and exceptions.....	193
7.1. Exception categories.....	193
7.1.1. HSM violation.....	193
7.1.2. ATA/ATAPI device error (non-NCQ / non-CHECK CONDITION)	194
7.1.3. ATAPI device CHECK CONDITION.....	195
7.1.4. ATA device error (NCQ).....	196
7.1.5. ATA bus error.....	196
7.1.6. PCI bus error.....	197
7.1.7. Late completion.....	197
7.1.8. Unknown error (timeout).....	197
7.1.9. Hotplug and power management exceptions.....	197
7.2. EH recovery actions.....	198
7.2.1. Clearing error condition.....	198
7.2.2. Reset.....	198
7.2.3. Reconfigure transport.....	200

8. ata_piix Internals	201
ich_pata_cable_detect	201
piix_pata_prereset	201
piix_set_piomode	202
do_pata_set_dmamode	203
piix_set_dmamode	204
ich_set_dmamode	205
piix_check_450nx_errata	206
piix_init_one	207
9. sata_sil Internals	209
sil_set_mode	209
sil_dev_config	209
10. Thanks.....	213

Chapter 1. Introduction

libATA is a library used inside the Linux kernel to support ATA host controllers and devices. libATA provides an ATA driver API, class transports for ATA and ATAPI devices, and SCSI<->ATA translation for ATA devices according to the T10 SAT specification.

This Guide documents the libATA driver API, library functions, library internals, and a couple sample ATA low-level drivers.

Chapter 2. libata Driver API

struct ata_port_operations is defined for every low-level libata hardware driver, and it controls how the low-level driver interfaces with the ATA and SCSI layers.

FIS-based drivers will hook into the system with ->qc_prep() and ->qc_issue() high-level hooks. Hardware which behaves in a manner similar to PCI IDE hardware may utilize several generic helpers, defining at a bare minimum the bus I/O addresses of the ATA shadow register blocks.

2.1. struct ata_port_operations

2.1.1. Disable ATA port

```
void (*port_disable) (struct ata_port *);
```

Called from ata_bus_probe() and ata_bus_reset() error paths, as well as when unregistering from the SCSI module (rmmod, hot unplug). This function should do whatever needs to be done to take the port out of use. In most cases, ata_port_disable() can be used as this hook.

Called from ata_bus_probe() on a failed probe. Called from ata_bus_reset() on a failed bus reset. Called from ata_scsi_release().

2.1.2. Post-IDENTIFY device configuration

```
void (*dev_config) (struct ata_port *, struct ata_device *);
```

Called after IDENTIFY [PACKET] DEVICE is issued to each device found. Typically used to apply device-specific fixups prior to issue of SET FEATURES - XFER MODE, and prior to operation.

Called by ata_device_add() after ata_dev_identify() determines a device is present.

This entry may be specified as NULL in ata_port_operations.

2.1.3. Set PIO/DMA mode

```
void (*set_piomode) (struct ata_port *, struct ata_device *);
```

```
void (*set_dmamode) (struct ata_port *, struct ata_device *);  
void (*post_set_mode) (struct ata_port *);  
unsigned int (*mode_filter) (struct ata_port *, struct ata_device *, unsigned int);
```

Hooks called prior to the issue of SET FEATURES - XFER MODE command. The optional `->mode_filter()` hook is called when libata has built a mask of the possible modes. This is passed to the `->mode_filter()` function which should return a mask of valid modes after filtering those unsuitable due to hardware limits. It is not valid to use this interface to add modes.

`dev->pio_mode` and `dev->dma_mode` are guaranteed to be valid when `->set_piomode()` and when `->set_dmamode()` is called. The timings for any other drive sharing the cable will also be valid at this point. That is the library records the decisions for the modes of each drive on a channel before it attempts to set any of them.

`->post_set_mode()` is called unconditionally, after the SET FEATURES - XFER MODE command completes successfully.

`->set_piomode()` is always called (if present), but `->set_dma_mode()` is only called if DMA is possible.

2.1.4. Taskfile read/write

```
void (*tf_load) (struct ata_port *ap, struct ata_taskfile *tf);  
void (*tf_read) (struct ata_port *ap, struct ata_taskfile *tf);
```

`->tf_load()` is called to load the given taskfile into hardware registers / DMA buffers. `->tf_read()` is called to read the hardware registers / DMA buffers, to obtain the current set of taskfile register values. Most drivers for taskfile-based hardware (PIO or MMIO) use `ata_tf_load()` and `ata_tf_read()` for these hooks.

2.1.5. PIO data read/write

```
void (*data_xfer) (struct ata_device *, unsigned char *, unsigned int, int);
```

All bmdma-style drivers must implement this hook. This is the low-level operation that actually copies the data bytes during a PIO data transfer. Typically the driver will choose one of `ata_pio_data_xfer_noirq()`, `ata_pio_data_xfer()`, or `ata_mmio_data_xfer()`.

2.1.6. ATA command execute

```
void (*exec_command)(struct ata_port *ap, struct ata_taskfile *tf);
```

causes an ATA command, previously loaded with `->tf_load()`, to be initiated in hardware. Most drivers for taskfile-based hardware use `ata_exec_command()` for this hook.

2.1.7. Per-cmd ATAPI DMA capabilities filter

```
int (*check_atapi_dma)(struct ata_queued_cmd *qc);
```

Allow low-level driver to filter ATA PACKET commands, returning a status indicating whether or not it is OK to use DMA for the supplied PACKET command.

This hook may be specified as NULL, in which case libata will assume that atapi dma can be supported.

2.1.8. Read specific ATA shadow registers

```
u8 (*check_status)(struct ata_port *ap);  
u8 (*check_altstatus)(struct ata_port *ap);
```

Reads the Status/AltStatus ATA shadow register from hardware. On some hardware, reading the Status register has the side effect of clearing the interrupt condition. Most drivers for taskfile-based hardware use `ata_check_status()` for this hook.

Note that because this is called from `ata_device_add()`, at least a dummy function that clears device interrupts must be provided for all drivers, even if the controller doesn't actually have a taskfile status register.

2.1.9. Select ATA device on bus

```
void (*dev_select)(struct ata_port *ap, unsigned int device);
```

Issues the low-level hardware command(s) that causes one of N hardware devices to be considered 'selected' (active and available for use) on the ATA bus. This generally has no meaning on FIS-based devices.

Most drivers for taskfile-based hardware use `ata_std_dev_select()` for this hook. Controllers which do not support second drives on a port (such as SATA controllers) will use `ata_noop_dev_select()`.

2.1.10. Private tuning method

```
void (*set_mode) (struct ata_port *ap);
```

By default libata performs drive and controller tuning in accordance with the ATA timing rules and also applies blacklists and cable limits. Some controllers need special handling and have custom tuning rules, typically raid controllers that use ATA commands but do not actually do drive timing.

Warning

This hook should not be used to replace the standard controller tuning logic when a controller has quirks. Replacing the default tuning logic in that case would bypass handling for drive and bridge quirks that may be important to data reliability. If a controller needs to filter the mode selection it should use the `mode_filter` hook instead.

2.1.11. Control PCI IDE BMDMA engine

```
void (*bmdma_setup) (struct ata_queued_cmd *qc);  
void (*bmdma_start) (struct ata_queued_cmd *qc);  
void (*bmdma_stop) (struct ata_port *ap);  
u8 (*bmdma_status) (struct ata_port *ap);
```

When setting up an IDE BMDMA transaction, these hooks arm (`->bmdma_setup`), fire (`->bmdma_start`), and halt (`->bmdma_stop`) the hardware's DMA engine. `->bmdma_status` is used to read the standard PCI IDE DMA Status register.

These hooks are typically either no-ops, or simply not implemented, in FIS-based drivers.

Most legacy IDE drivers use `ata_bmdma_setup()` for the `bmdma_setup()` hook. `ata_bmdma_setup()` will write the pointer to the PRD table to the IDE PRD Table Address register, enable DMA in the DMA Command register, and call `exec_command()` to begin the transfer.

Most legacy IDE drivers use `ata_bmdma_start()` for the `bmdma_start()` hook. `ata_bmdma_start()` will write the `ATA_DMA_START` flag to the DMA Command register.

Many legacy IDE drivers use `ata_bmdma_stop()` for the `bmdma_stop()` hook. `ata_bmdma_stop()` clears the `ATA_DMA_START` flag in the DMA command register.

Many legacy IDE drivers use `ata_bmdma_status()` as the `bmdma_status()` hook.

2.1.12. High-level taskfile hooks

```
void (*qc_prep) (struct ata_queued_cmd *qc);  
int (*qc_issue) (struct ata_queued_cmd *qc);
```

Higher-level hooks, these two hooks can potentially supercede several of the above taskfile/DMA engine hooks. `->qc_prep` is called after the buffers have been DMA-mapped, and is typically used to populate the hardware's DMA scatter-gather table. Most drivers use the standard `ata_qc_prep()` helper function, but more advanced drivers roll their own.

`->qc_issue` is used to make a command active, once the hardware and S/G tables have been prepared. IDE BMDMA drivers use the helper function `ata_qc_issue_prot()` for taskfile protocol-based dispatch. More advanced drivers implement their own `->qc_issue`.

`ata_qc_issue_prot()` calls `->tf_load()`, `->bmdma_setup()`, and `->bmdma_start()` as necessary to initiate a transfer.

2.1.13. Exception and probe handling (EH)

```
void (*eng_timeout) (struct ata_port *ap);  
void (*phy_reset) (struct ata_port *ap);
```

Deprecated. Use `->error_handler()` instead.

```
void (*freeze) (struct ata_port *ap);  
void (*thaw) (struct ata_port *ap);
```

`ata_port_freeze()` is called when HSM violations or some other condition disrupts normal operation of the port. A frozen port is not allowed to perform any operation until the port is thawed, which usually follows a successful reset.

The optional `->freeze()` callback can be used for freezing the port hardware-wise (e.g. mask interrupt and stop DMA engine). If a port cannot be frozen hardware-wise, the interrupt handler must ack and clear interrupts unconditionally while the port is frozen.

The optional `->thaw()` callback is called to perform the opposite of `->freeze()`: prepare the port for normal operation once again. Unmask interrupts, start DMA engine, etc.

```
void (*error_handler) (struct ata_port *ap);
```

`->error_handler()` is a driver's hook into probe, hotplug, and recovery and other exceptional conditions. The primary responsibility of an implementation is to call `ata_do_eh()` or `ata_bmdma_drive_eh()` with a set of EH hooks as arguments:

'prereset' hook (may be NULL) is called during an EH reset, before any other actions are taken.

'postreset' hook (may be NULL) is called after the EH reset is performed. Based on existing conditions, severity of the problem, and hardware capabilities,

Either 'softreset' (may be NULL) or 'hardreset' (may be NULL) will be called to perform the low-level EH reset.

```
void (*post_internal_cmd) (struct ata_queued_cmd *qc);
```

Perform any hardware-specific actions necessary to finish processing after executing a probe-time or EH-time command via `ata_exec_internal()`.

2.1.14. Hardware interrupt handling

```
irqreturn_t (*irq_handler)(int, void *, struct pt_regs *);  
void (*irq_clear) (struct ata_port *);
```

`->irq_handler` is the interrupt handling routine registered with the system, by libata. `->irq_clear` is called during probe just before the interrupt handler is registered, to be sure hardware is quiet.

The second argument, `dev_instance`, should be cast to a pointer to struct `ata_host_set`.

Most legacy IDE drivers use `ata_interrupt()` for the `irq_handler` hook, which scans all ports in the `host_set`, determines which queued command was active (if any), and calls `ata_host_intr(ap,qc)`.

Most legacy IDE drivers use `ata_bmdma_irq_clear()` for the `irq_clear()` hook, which simply clears the interrupt and error flags in the DMA status register.

2.1.15. SATA phy read/write

```
int (*scr_read) (struct ata_port *ap, unsigned int sc_reg,
                u32 *val);
int (*scr_write) (struct ata_port *ap, unsigned int sc_reg,
                 u32 val);
```

Read and write standard SATA phy registers. Currently only used if `->phy_reset` hook called the `sata_phy_reset()` helper function. `sc_reg` is one of `SCR_STATUS`, `SCR_CONTROL`, `SCR_ERROR`, or `SCR_ACTIVE`.

2.1.16. Init and shutdown

```
int (*port_start) (struct ata_port *ap);
void (*port_stop) (struct ata_port *ap);
void (*host_stop) (struct ata_host_set *host_set);
```

`->port_start()` is called just after the data structures for each port are initialized. Typically this is used to alloc per-port DMA buffers / tables / rings, enable DMA engines, and similar tasks. Some drivers also use this entry point as a chance to allocate driver-private memory for `ap->private_data`.

Many drivers use `ata_port_start()` as this hook or call it from their own `port_start()` hooks. `ata_port_start()` allocates space for a legacy IDE PRD table and returns.

`->port_stop()` is called after `->host_stop()`. It's sole function is to release DMA/memory resources, now that they are no longer actively being used. Many drivers also free driver-private data from port at this time.

Many drivers use `ata_port_stop()` as this hook, which frees the PRD table.

`->host_stop()` is called after all `->port_stop()` calls have completed. The hook must finalize hardware shutdown, release DMA and other resources, etc. This hook may be specified as `NULL`, in which case it is not called.

Chapter 3. Error handling

This chapter describes how errors are handled under libata. Readers are advised to read SCSI EH (Documentation/scsi/scsi_eh.txt) and ATA exceptions doc first.

3.1. Origins of commands

In libata, a command is represented with struct `ata_queued_cmd` or `qc`. `qc`'s are preallocated during port initialization and repetitively used for command executions. Currently only one `qc` is allocated per port but yet-to-be-merged NCQ branch allocates one for each tag and maps each `qc` to NCQ tag 1-to-1.

libata commands can originate from two sources - libata itself and SCSI midlayer. libata internal commands are used for initialization and error handling. All normal blk requests and commands for SCSI emulation are passed as SCSI commands through `queuecommand` callback of SCSI host template.

3.2. How commands are issued

Internal commands

First, `qc` is allocated and initialized using `ata_qc_new_init()`. Although `ata_qc_new_init()` doesn't implement any wait or retry mechanism when `qc` is not available, internal commands are currently issued only during initialization and error recovery, so no other command is active and allocation is guaranteed to succeed.

Once allocated `qc`'s taskfile is initialized for the command to be executed. `qc` currently has two mechanisms to notify completion. One is via `qc->complete_fn()` callback and the other is completion `qc->waiting`. `qc->complete_fn()` callback is the asynchronous path used by normal SCSI translated commands and `qc->waiting` is the synchronous (issuer sleeps in process context) path used by internal commands.

Once initialization is complete, `host_set` lock is acquired and the `qc` is issued.

SCSI commands

All libata drivers use `ata_scsi_queuecmd()` as `hostt->queuecommand` callback. `scmds` can either be simulated or translated. No `qc` is involved in processing a simulated `scmd`. The result is computed right away and the `scmd` is completed.

For a translated scmd, `ata_qc_new_init()` is invoked to allocate a qc and the scmd is translated into the qc. SCSI midlayer's completion notification function pointer is stored into `qc->scsidone`.

`qc->complete_fn()` callback is used for completion notification. ATA commands use `ata_scsi_qc_complete()` while ATAPI commands use `atapi_qc_complete()`. Both functions end up calling `qc->scsidone` to notify upper layer when the qc is finished. After translation is completed, the qc is issued with `ata_qc_issue()`.

Note that SCSI midlayer invokes `hostt->queuecommand` while holding `host_set` lock, so all above occur while holding `host_set` lock.

3.3. How commands are processed

Depending on which protocol and which controller are used, commands are processed differently. For the purpose of discussion, a controller which uses taskfile interface and all standard callbacks is assumed.

Currently 6 ATA command protocols are used. They can be sorted into the following four categories according to how they are processed.

ATA NO DATA or DMA

`ATA_PROT_NODATA` and `ATA_PROT_DMA` fall into this category. These types of commands don't require any software intervention once issued. Device will raise interrupt on completion.

ATA PIO

`ATA_PROT_PIO` is in this category. `libata` currently implements PIO with polling. `ATA_NIEN` bit is set to turn off interrupt and `pio_task` on `ata_wq` performs polling and IO.

ATAPI NODATA or DMA

`ATA_PROT_ATAPI_NODATA` and `ATA_PROT_ATAPI_DMA` are in this category. `packet_task` is used to poll BSY bit after issuing `PACKET` command. Once BSY is turned off by the device, `packet_task` transfers CDB and hands off processing to interrupt handler.

ATAPI PIO

`ATA_PROT_ATAPI` is in this category. `ATA_NIEN` bit is set and, as in ATAPI NODATA or DMA, `packet_task` submits cdb. However, after submitting cdb, further processing (data transfer) is handed off to `pio_task`.

3.4. How commands are completed

Once issued, all qc's are either completed with `ata_qc_complete()` or time out. For commands which are handled by interrupts, `ata_host_intr()` invokes `ata_qc_complete()`, and, for PIO tasks, `pio_task` invokes `ata_qc_complete()`. In error cases, `packet_task` may also complete commands.

`ata_qc_complete()` does the following.

1. DMA memory is unmapped.
2. `ATA_QCFLAG_ACTIVE` is cleared from `qc->flags`.
3. `qc->complete_fn()` callback is invoked. If the return value of the callback is not zero. Completion is short circuited and `ata_qc_complete()` returns.
4. `__ata_qc_complete()` is called, which does
 - a. `qc->flags` is cleared to zero.
 - b. `ap->active_tag` and `qc->tag` are poisoned.
 - c. `qc->waiting` is cleared & completed (in that order).
 - d. qc is deallocated by clearing appropriate bit in `ap->qactive`.

So, it basically notifies upper layer and deallocates qc. One exception is short-circuit path in #3 which is used by `atapi_qc_complete()`.

For all non-ATAPI commands, whether it fails or not, almost the same code path is taken and very little error handling takes place. A qc is completed with success status if it succeeded, with failed status otherwise.

However, failed ATAPI commands require more handling as REQUEST SENSE is needed to acquire sense data. If an ATAPI command fails, `ata_qc_complete()` is invoked with error status, which in turn invokes `atapi_qc_complete()` via `qc->complete_fn()` callback.

This makes `atapi_qc_complete()` set `scmd->result` to `SAM_STAT_CHECK_CONDITION`, complete the `scmd` and return 1. As the sense data is empty but `scmd->result` is `CHECK_CONDITION`, SCSI midlayer will invoke EH for the `scmd`, and returning 1 makes `ata_qc_complete()` to return without deallocating the qc. This leads us to `ata_scsi_error()` with partially completed qc.

3.5. ata_scsi_error()

`ata_scsi_error()` is the current `transport->eh_strategy_handler()` for libata. As discussed above, this will be entered in two cases - timeout and ATAPI error

completion. This function calls low level libata driver's `eng_timeout()` callback, the standard callback for which is `ata_eng_timeout()`. It checks if a qc is active and calls `ata_qc_timeout()` on the qc if so. Actual error handling occurs in `ata_qc_timeout()`.

If EH is invoked for timeout, `ata_qc_timeout()` stops BMDMA and completes the qc. Note that as we're currently in EH, we cannot call `scsi_done`. As described in SCSI EH doc, a recovered scmd should be either retried with `scsi_queue_insert()` or finished with `scsi_finish_command()`. Here, we override `qc->scsidone` with `scsi_finish_command()` and calls `ata_qc_complete()`.

If EH is invoked due to a failed ATAPI qc, the qc here is completed but not deallocated. The purpose of this half-completion is to use the qc as place holder to make EH code reach this place. This is a bit hackish, but it works.

Once control reaches here, the qc is deallocated by invoking `__ata_qc_complete()` explicitly. Then, internal qc for REQUEST SENSE is issued. Once sense data is acquired, scmd is finished by directly invoking `scsi_finish_command()` on the scmd. Note that as we already have completed and deallocated the qc which was associated with the scmd, we don't need to/cannot call `ata_qc_complete()` again.

3.6. Problems with the current EH

- Error representation is too crude. Currently any and all error conditions are represented with ATA STATUS and ERROR registers. Errors which aren't ATA device errors are treated as ATA device errors by setting ATA_ERR bit. Better error descriptor which can properly represent ATA and other errors/exceptions is needed.
- When handling timeouts, no action is taken to make device forget about the timed out command and ready for new commands.
- EH handling via `ata_scsi_error()` is not properly protected from usual command processing. On EH entrance, the device is not in quiescent state. Timed out commands may succeed or fail any time. `pio_task` and `atapi_task` may still be running.
- Too weak error recovery. Devices / controllers causing HSM mismatch errors and other errors quite often require reset to return to known state. Also, advanced error handling is necessary to support features like NCQ and hotplug.
- ATA errors are directly handled in the interrupt handler and PIO errors in `pio_task`. This is problematic for advanced error handling for the following reasons.

First, advanced error handling often requires context and internal qc execution.

Second, even a simple failure (say, CRC error) needs information gathering and could trigger complex error handling (say, resetting & reconfiguring). Having multiple code paths to gather information, enter EH and trigger actions makes life painful.

Third, scattered EH code makes implementing low level drivers difficult. Low level drivers override libata callbacks. If EH is scattered over several places, each affected callbacks should perform its part of error handling. This can be error prone and painful.

Chapter 4. libata Library

atapi_cmd_type

LINUX

Kernel Hackers Manual February 2009

Name

`atapi_cmd_type` — Determine ATAPI command type from SCSI opcode

Synopsis

```
int atapi_cmd_type (u8 opcode);
```

Arguments

opcode

SCSI opcode

Description

Determine ATAPI command type from *opcode*.

LOCKING

None.

RETURNS

`ATAPI_{READ|WRITE|READ_CD|PASS_THRU|MISC}`

ata_tf_to_fis

LINUX

Kernel Hackers Manual February 2009

Name

`ata_tf_to_fis` — Convert ATA taskfile to SATA FIS structure

Synopsis

```
void ata_tf_to_fis (const struct ata_taskfile * tf, u8 pmp,  
int is_cmd, u8 * fis);
```

Arguments

tf

Taskfile to convert

pmp

Port multiplier port

is_cmd

This FIS is for command

fis

Buffer into which data will output

Description

Converts a standard ATA taskfile to a Serial ATA FIS structure (Register - Host to Device).

LOCKING

Inherited from caller.

ata_tf_from_fis

LINUX

Kernel Hackers Manual February 2009

Name

`ata_tf_from_fis` — Convert SATA FIS to ATA taskfile

Synopsis

```
void ata_tf_from_fis (const u8 * fis, struct ata_taskfile *  
tf);
```

Arguments

fis

Buffer from which data will be input

tf

Taskfile to output

Description

Converts a serial ATA FIS structure to a standard ATA taskfile.

LOCKING

Inherited from caller.

ata_pack_xfermask

LINUX

Kernel Hackers Manual February 2009

Name

`ata_pack_xfermask` — Pack pio, mwdma and udma masks into xfer_mask

Synopsis

```
unsigned long ata_pack_xfermask (unsigned long pio_mask,  
unsigned long mwdma_mask, unsigned long udma_mask);
```

Arguments

pio_mask

pio_mask

mwdma_mask

mwdma_mask

udma_mask

udma_mask

Description

Pack *pio_mask*, *mwdma_mask* and *udma_mask* into a single unsigned int *xfer_mask*.

LOCKING

None.

RETURNS

Packed *xfer_mask*.

ata_unpack_xfermask

LINUX

Kernel Hackers Manual February 2009

Name

`ata_unpack_xfermask` — Unpack *xfer_mask* into *pio*, *mwdma* and *udma* masks

Synopsis

```
void ata_unpack_xfermask (unsigned long xfer_mask, unsigned  
long * pio_mask, unsigned long * mwdma_mask, unsigned long *  
udma_mask);
```

Arguments

xfer_mask

xfer_mask to unpack

pio_mask

resulting pio_mask

mwdma_mask

resulting mwdma_mask

udma_mask

resulting udma_mask

Description

Unpack *xfer_mask* into *pio_mask*, *mwdma_mask* and *udma_mask*. Any NULL destination masks will be ignored.

ata_xfer_mask2mode

LINUX

Kernel Hackers Manual February 2009

Name

`ata_xfer_mask2mode` — Find matching XFER_* for the given xfer_mask

Synopsis

```
u8 ata_xfer_mask2mode (unsigned long xfer_mask);
```

Arguments

xfer_mask

xfer_mask of interest

Description

Return matching XFER_* value for *xfer_mask*. Only the highest bit of *xfer_mask* is considered.

LOCKING

None.

RETURNS

Matching XFER_* value, 0xff if no match found.

ata_xfer_mode2mask

LINUX

Kernel Hackers Manual February 2009

Name

`ata_xfer_mode2mask` — Find matching *xfer_mask* for XFER_*

Synopsis

```
unsigned long ata_xfer_mode2mask (u8 xfer_mode);
```

Arguments

xfer_mode

XFER_* of interest

Description

Return matching xfer_mask for *xfer_mode*.

LOCKING

None.

RETURNS

Matching xfer_mask, 0 if no match found.

ata_xfer_mode2shift

LINUX

Kernel Hackers Manual February 2009

Name

`ata_xfer_mode2shift` — Find matching xfer_shift for XFER_*

Synopsis

```
int ata_xfer_mode2shift (unsigned long xfer_mode);
```


Arguments

xfer_mode

XFER_* of interest

Description

Return matching xfer_shift for *xfer_mode*.

LOCKING

None.

RETURNS

Matching xfer_shift, -1 if no match found.

ata_mode_string

LINUX

Kernel Hackers Manual February 2009

Name

ata_mode_string — convert xfer_mask to string

Synopsis

```
const char * ata_mode_string (unsigned long xfer_mask);
```

Arguments

xfer_mask

mask of bits supported; only highest bit counts.

Description

Determine string which represents the highest speed (highest bit in *modemask*).

LOCKING

None.

RETURNS

Constant C string representing highest speed listed in *mode_mask*, or the constant C string “<n/a>”.

ata_dev_classify

LINUX

Kernel Hackers Manual February 2009

Name

`ata_dev_classify` — determine device type based on ATA-spec signature

Synopsis

```
unsigned int ata_dev_classify (const struct ata_taskfile *  
tf);
```

Arguments

tf

ATA taskfile register set for device to be identified

Description

Determine from taskfile register contents whether a device is ATA or ATAPI, as per “Signature and persistence” section of ATA/PI spec (volume 1, sect 5.14).

LOCKING

None.

RETURNS

Device type, `ATA_DEV_ATA`, `ATA_DEV_ATAPI`, `ATA_DEV_PMP` or `ATA_DEV_UNKNOWN` the event of failure.

ata_id_string

LINUX

Kernel Hackers Manual February 2009

Name

`ata_id_string` — Convert IDENTIFY DEVICE page into string

Synopsis

```
void ata_id_string (const u16 * id, unsigned char * s,
unsigned int ofs, unsigned int len);
```

Arguments

id

IDENTIFY DEVICE results we will examine

s

string into which data is output

ofs

offset into identify device page

len

length of string to return. must be an even number.

Description

The strings in the IDENTIFY DEVICE page are broken up into 16-bit chunks. Run through the string, and output each 8-bit chunk linearly, regardless of platform.

LOCKING

caller.

ata_id_c_string

LINUX

Kernel Hackers Manual February 2009

Name

`ata_id_c_string` — Convert IDENTIFY DEVICE page into C string

Synopsis

```
void ata_id_c_string (const ul6 * id, unsigned char * s,
unsigned int ofs, unsigned int len);
```

Arguments

id

IDENTIFY DEVICE results we will examine

s

string into which data is output

ofs

offset into identify device page

len

length of string to return. must be an odd number.

Description

This function is identical to `ata_id_string` except that it trims trailing spaces and terminates the resulting string with null. *len* must be actual maximum length (even number) + 1.

LOCKING

caller.

ata_id_xfermask

LINUX

Name

`ata_id_xfermask` — Compute xfermask from the given IDENTIFY data

Synopsis

```
unsigned long ata_id_xfermask (const u16 * id);
```

Arguments

id

IDENTIFY data to compute xfer mask from

Description

Compute the xfermask for this device. This is not as trivial as it seems if we must consider early devices correctly.

FIXME

pre IDE drive timing (do we care ?).

LOCKING

None.

RETURNS

Computed xfermask

ata_pio_need_iordy

LINUX

Kernel Hackers Manual February 2009

Name

`ata_pio_need_iordy` — check if iordy needed

Synopsis

```
unsigned int ata_pio_need_iordy (const struct ata_device *  
adev);
```

Arguments

adev

ATA device

Description

Check if the current speed of the device requires IORDY. Used by various controllers for chip configuration.

ata_do_dev_read_id

LINUX

Name

`ata_do_dev_read_id` — default ID read method

Synopsis

```
unsigned int ata_do_dev_read_id (struct ata_device * dev,  
struct ata_taskfile * tf, u16 * id);
```

Arguments

dev

device

tf

proposed taskfile

id

data buffer

Description

Issue the identify taskfile and hand back the buffer containing identify data. For some RAID controllers and for pre ATA devices this function is wrapped or replaced by the driver

ata_cable_40wire

LINUX

Name

`ata_cable_40wire` — return 40 wire cable type

Synopsis

```
int ata_cable_40wire (struct ata_port * ap);
```

Arguments

ap

port

Description

Helper method for drivers which want to hardwire 40 wire cable detection.

ata_cable_80wire

LINUX

Name

`ata_cable_80wire` — return 80 wire cable type

Synopsis

```
int ata_cable_80wire (struct ata_port * ap);
```

Arguments

ap

port

Description

Helper method for drivers which want to hardwire 80 wire cable detection.

ata_cable_unknown

LINUX

Kernel Hackers Manual February 2009

Name

`ata_cable_unknown` — return unknown PATA cable.

Synopsis

```
int ata_cable_unknown (struct ata_port * ap);
```

Arguments

ap
port

Description

Helper method for drivers which have no PATA cable detection.

ata_cable_ignore

LINUX

Kernel Hackers Manual February 2009

Name

`ata_cable_ignore` — return ignored PATA cable.

Synopsis

```
int ata_cable_ignore (struct ata_port * ap);
```

Arguments

ap
port

Description

Helper method for drivers which don't use cable type to limit transfer mode.

ata_cable_sata

LINUX

Kernel Hackers Manual February 2009

Name

`ata_cable_sata` — return SATA cable type

Synopsis

```
int ata_cable_sata (struct ata_port * ap);
```

Arguments

ap
port

Description

Helper method for drivers which have SATA cables

ata_port_probe

LINUX

Name

`ata_port_probe` — Mark port as enabled

Synopsis

```
void ata_port_probe (struct ata_port * ap);
```

Arguments

ap

Port for which we indicate enablement

Description

Modify *ap* data structure such that the system thinks that the entire port is enabled.

LOCKING

host lock, or some other form of serialization.

`ata_dev_pair`

LINUX

Name

`ata_dev_pair` — return other device on cable

Synopsis

```
struct ata_device * ata_dev_pair (struct ata_device * adev);
```

Arguments

adev

device

Description

Obtain the other device on the same cable, or if none is present NULL is returned

ata_port_disable

LINUX

Name

`ata_port_disable` — Disable port.

Synopsis

```
void ata_port_disable (struct ata_port * ap);
```

Arguments

ap

Port to be disabled.

Description

Modify *ap* data structure such that the system thinks that the entire port is disabled, and should never attempt to probe or communicate with devices on this port.

LOCKING

host lock, or some other form of serialization.

sata_set_spd

LINUX

Kernel Hackers Manual February 2009

Name

`sata_set_spd` — set SATA spd according to spd limit

Synopsis

```
int sata_set_spd (struct ata_link * link);
```

Arguments

link

Link to set SATA spd for

Description

Set SATA spd of *link* according to `sata_spd_limit`.

LOCKING

Inherited from caller.

RETURNS

0 if spd doesn't need to be changed, 1 if spd has been changed. Negative `errno` if SCR registers are inaccessible.

ata_timing_cycle2mode

LINUX

Kernel Hackers Manual February 2009

Name

`ata_timing_cycle2mode` — find xfer mode for the specified cycle duration

Synopsis

```
u8 ata_timing_cycle2mode (unsigned int xfer_shift, int cycle);
```

Arguments

xfer_shift

ATA_SHIFT_* value for transfer type to examine.

cycle

cycle duration in ns

Description

Return matching xfer mode for *cycle*. The returned mode is of the transfer type specified by *xfer_shift*. If *cycle* is too slow for *xfer_shift*, 0xff is returned. If *cycle* is faster than the fastest known mode, the fastest mode is returned.

LOCKING

None.

RETURNS

Matching xfer_mode, 0xff if no match found.

ata_do_set_mode

LINUX

Name

`ata_do_set_mode` — Program timings and issue SET FEATURES - XFER

Synopsis

```
int ata_do_set_mode (struct ata_link * link, struct ata_device  
** r_failed_dev);
```

Arguments

link

link on which timings will be programmed

r_failed_dev

out parameter for failed device

Description

Standard implementation of the function used to tune and set ATA device disk transfer mode (PIO3, UDMA6, etc.). If `ata_dev_set_mode` fails, pointer to the failing device is returned in *r_failed_dev*.

LOCKING

PCI/etc. bus probe sem.

RETURNS

0 on success, negative errno otherwise

ata_wait_after_reset

LINUX

Kernel Hackers Manual February 2009

Name

`ata_wait_after_reset` — wait for link to become ready after reset

Synopsis

```
int ata_wait_after_reset (struct ata_link * link, unsigned  
long deadline, int (*check_ready) (struct ata_link *link));
```

Arguments

link

link to be waited on

deadline

deadline jiffies for the operation

check_ready

callback to check link readiness

Description

Wait for *link* to become ready after reset.

LOCKING

EH context.

RETURNS

0 if *link* is ready before *deadline*; otherwise, -errno.

sata_link_debounce

LINUX

Kernel Hackers Manual February 2009

Name

sata_link_debounce — debounce SATA phy status

Synopsis

```
int sata_link_debounce (struct ata_link * link, const unsigned  
long * params, unsigned long deadline);
```

Arguments

link

ATA link to debounce SATA phy status for

params

timing parameters { interval, duration, timeout } in msec

deadline

deadline jiffies for the operation

Description

Make sure SStatus of *link* reaches stable state, determined by holding the same value where DET is not 1 for *duration* polled every *interval*, before *timeout*. Timeout constraints the beginning of the stable state. Because DET gets stuck at 1 on some controllers after hot unplugging, this functions waits until timeout then returns 0 if DET is stable at 1.

timeout is further limited by *deadline*. The sooner of the two is used.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, -errno on failure.

sata_link_resume

LINUX

Kernel Hackers Manual February 2009

Name

sata_link_resume — resume SATA link

Synopsis

```
int sata_link_resume (struct ata_link * link, const unsigned
long * params, unsigned long deadline);
```

Arguments

link

ATA link to resume SATA

params

timing parameters { interval, duration, timeout } in msec

deadline

deadline jiffies for the operation

Description

Resume SATA phy *link* and debounce it.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, -errno on failure.

ata_std_prereset

LINUX

Kernel Hackers Manual February 2009

Name

ata_std_prereset — prepare for reset

Synopsis

```
int ata_std_prereset (struct ata_link * link, unsigned long
deadline);
```

Arguments

link

ATA link to be reset

deadline

deadline jiffies for the operation

Description

link is about to be reset. Initialize it. Failure from prereset makes libata abort whole reset sequence and give up that port, so prereset should be best-effort. It does its best to prepare for reset sequence but if things go wrong, it should just whine, not fail.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, -errno otherwise.

sata_link_hardreset

LINUX

Name

`sata_link_hardreset` — reset link via SATA phy reset

Synopsis

```
int sata_link_hardreset (struct ata_link * link, const
unsigned long * timing, unsigned long deadline, bool * online,
int (*check_ready) (struct ata_link *));
```

Arguments

link

link to reset

timing

timing parameters { interval, duration, timeout } in msec

deadline

deadline jiffies for the operation

online

optional out parameter indicating link onlineness

check_ready

optional callback to check link readiness

Description

SATA phy-reset *link* using DET bits of SControl register. After hardreset, link readiness is waited upon using `ata_wait_ready` if *check_ready* is specified. LLDs are allowed to not specify *check_ready* and wait itself after this function returns. Device classification is LLD's responsibility.

**online* is set to one iff reset succeeded and *link* is online after reset.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, -errno otherwise.

sata_std_hardreset

LINUX

Kernel Hackers Manual February 2009

Name

sata_std_hardreset — COMRESET w/o waiting or classification

Synopsis

```
int sata_std_hardreset (struct ata_link * link, unsigned int *  
class, unsigned long deadline);
```

Arguments

link

link to reset

class

resulting class of attached device

deadline

deadline jiffies for the operation

Description

Standard SATA COMRESET w/o waiting or classification.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 if link offline, -EAGAIN if link online, -errno on errors.

ata_std_postreset

LINUX

Kernel Hackers Manual February 2009

Name

`ata_std_postreset` — standard postreset callback

Synopsis

```
void ata_std_postreset (struct ata_link * link, unsigned int *  
classes);
```

Arguments

link

the target `ata_link`

classes

classes of attached devices

Description

This function is invoked after a successful reset. Note that the device might have been reset more than once using different reset methods before `postreset` is invoked.

LOCKING

Kernel thread context (may sleep)

ata_std_qc_defer

LINUX

Kernel Hackers Manual February 2009

Name

`ata_std_qc_defer` — Check whether a qc needs to be deferred

Synopsis

```
int ata_std_qc_defer (struct ata_queued_cmd * qc);
```

Arguments

qc

ATA command in question

Description

Non-NCQ commands cannot run with any other command, NCQ or not. As upper layer only knows the queue depth, we are responsible for maintaining exclusion. This function checks whether a new command *qc* can be issued.

LOCKING

spin_lock_irqsave(host lock)

RETURNS

ATA_DEFER_* if deferring is needed, 0 otherwise.

ata_sg_init

LINUX

Kernel Hackers Manual February 2009

Name

ata_sg_init — Associate command with scatter-gather table.

Synopsis

```
void ata_sg_init (struct ata_queued_cmd * qc, struct  
scatterlist * sg, unsigned int n_elem);
```

Arguments

qc

Command to be associated

sg

Scatter-gather table.

n_elem

Number of elements in s/g table.

Description

Initialize the data-related elements of `queued_cmd` *qc* to point to a scatter-gather table *sg*, containing *n_elem* elements.

LOCKING

`spin_lock_irqsave(host lock)`

ata_qc_complete

LINUX

Kernel Hackers Manual February 2009

Name

`ata_qc_complete` — Complete an active ATA command

Synopsis

```
void ata_qc_complete (struct ata_queued_cmd * qc);
```

Arguments

qc

Command to complete

Description

Indicate to the mid and upper layers that an ATA command has completed, with either an ok or not-ok status.

LOCKING

spin_lock_irqsave(host lock)

ata_qc_complete_multiple

LINUX

Kernel Hackers Manual February 2009

Name

`ata_qc_complete_multiple` — Complete multiple qcs successfully

Synopsis

```
int ata_qc_complete_multiple (struct ata_port * ap, u32
qc_active);
```

Arguments

ap

port in question

qc_active

new qc_active mask

Description

Complete in-flight commands. This functions is meant to be called from low-level driver's interrupt routine to complete requests normally. *ap->qc_active* and *qc_active* is compared and commands are completed accordingly.

LOCKING

spin_lock_irqsave(host lock)

RETURNS

Number of completed commands on success, -errno otherwise.

sata_scr_valid

LINUX

Kernel Hackers Manual February 2009

Name

sata_scr_valid — test whether SCRs are accessible

Synopsis

```
int sata_scr_valid (struct ata_link * link);
```

Arguments

link

ATA link to test SCR accessibility for

Description

Test whether SCRs are accessible for *link*.

LOCKING

None.

RETURNS

1 if SCRs are accessible, 0 otherwise.

sata_scr_read

LINUX

Kernel Hackers Manual February 2009

Name

`sata_scr_read` — read SCR register of the specified port

Synopsis

```
int sata_scr_read (struct ata_link * link, int reg, u32 *  
val);
```

Arguments

link

ATA link to read SCR for

reg

SCR to read

val

Place to store read value

Description

Read SCR register *reg* of *link* into **val*. This function is guaranteed to succeed if *link* is *ap->link*, the cable type of the port is SATA and the port implements *->scr_read*.

LOCKING

None if *link* is *ap->link*. Kernel thread context otherwise.

RETURNS

0 on success, negative *errno* on failure.

sata_scr_write

LINUX

Kernel Hackers Manual February 2009

Name

`sata_scr_write` — write SCR register of the specified port

Synopsis

```
int sata_scr_write (struct ata_link * link, int reg, u32 val);
```

Arguments

link

ATA link to write SCR for

reg

SCR to write

val

value to write

Description

Write *val* to SCR register *reg* of *link*. This function is guaranteed to succeed if *link* is ap->link, the cable type of the port is SATA and the port implements ->scr_read.

LOCKING

None if *link* is ap->link. Kernel thread context otherwise.

RETURNS

0 on success, negative errno on failure.

sata_scr_write_flush

LINUX

Kernel Hackers Manual February 2009

Name

`sata_scr_write_flush` — write SCR register of the specified port and flush

Synopsis

```
int sata_scr_write_flush (struct ata_link * link, int reg, u32  
val);
```

Arguments

link

ATA link to write SCR for

reg

SCR to write

val

value to write

Description

This function is identical to `sata_scr_write` except that this function performs flush after writing to the register.

LOCKING

None if *link* is `ap->link`. Kernel thread context otherwise.

RETURNS

0 on success, negative `errno` on failure.

ata_link_online

LINUX

Kernel Hackers Manual February 2009

Name

`ata_link_online` — test whether the given link is online

Synopsis

```
bool ata_link_online (struct ata_link * link);
```

Arguments

link

ATA link to test

Description

Test whether *link* is online. This is identical to `ata_phys_link_online` when there's no slave link. When there's a slave link, this function should only be called on the master link and will return true if any of M/S links is online.

LOCKING

None.

RETURNS

True if the port online status is available and online.

ata_link_offline

LINUX

Kernel Hackers Manual February 2009

Name

`ata_link_offline` — test whether the given link is offline

Synopsis

```
bool ata_link_offline (struct ata_link * link);
```

Arguments

link

ATA link to test

Description

Test whether *link* is offline. This is identical to `ata_phys_link_offline` when there's no slave link. When there's a slave link, this function should only be called on the master link and will return true if both M/S links are offline.

LOCKING

None.

RETURNS

True if the port offline status is available and offline.

ata_host_suspend

LINUX

Kernel Hackers Manual February 2009

Name

`ata_host_suspend` — suspend host

Synopsis

```
int ata_host_suspend (struct ata_host * host, pm_message_t  
mesg);
```

Arguments

host

host to suspend

msg

PM message

Description

Suspend *host*. Actual operation is performed by EH. This function requests EH to perform PM operations and waits for EH to finish.

LOCKING

Kernel thread context (may sleep).

RETURNS

0 on success, -errno on failure.

ata_host_resume

LINUX

Kernel Hackers Manual February 2009

Name

ata_host_resume — resume host

Synopsis

```
void ata_host_resume (struct ata_host * host);
```

Arguments

host

host to resume

Description

Resume *host*. Actual operation is performed by EH. This function requests EH to perform PM operations and returns. Note that all resume operations are performed parallely.

LOCKING

Kernel thread context (may sleep).

ata_port_start

LINUX

Kernel Hackers Manual February 2009

Name

`ata_port_start` — Set port up for dma.

Synopsis

```
int ata_port_start (struct ata_port * ap);
```

Arguments

ap

Port to initialize

Description

Called just after data structures for each port are initialized. Allocates space for PRD table.

May be used as the `port_start` entry in `ata_port_operations`.

LOCKING

Inherited from caller.

ata_host_alloc

LINUX

Kernel Hackers Manual February 2009

Name

`ata_host_alloc` — allocate and init basic ATA host resources

Synopsis

```
struct ata_host * ata_host_alloc (struct device * dev, int  
max_ports);
```

Arguments

dev

generic device this host is associated with

max_ports

maximum number of ATA ports associated with this host

Description

Allocate and initialize basic ATA host resources. LLD calls this function to allocate a host, initializes it fully and attaches it using `ata_host_register`.

max_ports ports are allocated and `host->n_ports` is initialized to *max_ports*. The caller is allowed to decrease `host->n_ports` before calling `ata_host_register`. The unused ports will be automatically freed on registration.

RETURNS

Allocate ATA host on success, NULL on failure.

LOCKING

Inherited from calling layer (may sleep).

ata_host_alloc_pinfo

LINUX

Kernel Hackers Manual February 2009

Name

`ata_host_alloc_pinfo` — alloc host and init with `port_info` array

Synopsis

```
struct ata_host * ata_host_alloc_pinfo (struct device * dev,
const struct ata_port_info * const * ppi, int n_ports);
```

Arguments

dev

generic device this host is associated with

ppi

array of ATA `port_info` to initialize host with

n_ports

number of ATA ports attached to this host

Description

Allocate ATA host and initialize with info from *ppi*. If NULL terminated, *ppi* may contain fewer entries than *n_ports*. The last entry will be used for the remaining ports.

RETURNS

Allocate ATA host on success, NULL on failure.

LOCKING

Inherited from calling layer (may sleep).

ata_slave_link_init

LINUX

Kernel Hackers Manual February 2009

Name

`ata_slave_link_init` — initialize slave link

Synopsis

```
int ata_slave_link_init (struct ata_port * ap);
```

Arguments

ap

port to initialize slave link for

Description

Create and initialize slave link for *ap*. This enables slave link handling on the port.

In libata, a port contains links and a link contains devices. There is single host link but if a PMP is attached to it, there can be multiple fan-out links. On SATA, there's usually a single device connected to a link but PATA and SATA controllers emulating TF based interface can have two - master and slave.

However, there are a few controllers which don't fit into this abstraction too well - SATA controllers which emulate TF interface with both master and slave devices

but also have separate SCR register sets for each device. These controllers need separate links for physical link handling (e.g. onlineness, link speed) but should be treated like a traditional M/S controller for everything else (e.g. command issue, softreset).

slave_link is libata's way of handling this class of controllers without impacting core layer too much. For anything other than physical link handling, the default host link is used for both master and slave. For physical link handling, separate *ap->slave_link* is used. All dirty details are implemented inside libata core layer. From LLD's POV, the only difference is that prereset, hardreset and postreset are called once more for the slave link, so the reset sequence looks like the following.

```
prereset(M) -> prereset(S) -> hardreset(M) -> hardreset(S) -> softreset(M) ->
postreset(M) -> postreset(S)
```

Note that softreset is called only for the master. Softreset resets both M/S by definition, so SRST on master should handle both (the standard method will work just fine).

LOCKING

Should be called before host is registered.

RETURNS

0 on success, -errno on failure.

ata_host_start

LINUX

Kernel Hackers Manual February 2009

Name

`ata_host_start` — start and freeze ports of an ATA host

Synopsis

```
int ata_host_start (struct ata_host * host);
```

Arguments

host

ATA host to start ports for

Description

Start and then freeze ports of *host*. Started status is recorded in *host->flags*, so this function can be called multiple times. Ports are guaranteed to get started only once. If *host->ops* isn't initialized yet, its set to the first non-dummy port ops.

LOCKING

Inherited from calling layer (may sleep).

RETURNS

0 if all ports are started successfully, -errno otherwise.

ata_host_init

LINUX

Kernel Hackers Manual February 2009

Name

`ata_host_init` — Initialize a host struct

Synopsis

```
void ata_host_init (struct ata_host * host, struct device *
dev, unsigned long flags, struct ata_port_operations * ops);
```

Arguments

host

host to initialize

dev

device host is attached to

flags

host flags

ops

port_ops

LOCKING

PCI/etc. bus probe sem.

ata_host_register

LINUX

Kernel Hackers Manual February 2009

Name

`ata_host_register` — register initialized ATA host

Synopsis

```
int ata_host_register (struct ata_host * host, struct  
scsi_host_template * sht);
```

Arguments

host

ATA host to register

sht

template for SCSI host

Description

Register initialized ATA host. *host* is allocated using `ata_host_alloc` and fully initialized by LLD. This function starts ports, registers *host* with ATA and SCSI layers and probe registered devices.

LOCKING

Inherited from calling layer (may sleep).

RETURNS

0 on success, -errno otherwise.

ata_host_activate

LINUX

Name

`ata_host_activate` — start host, request IRQ and register it

Synopsis

```
int ata_host_activate (struct ata_host * host, int irq,  
irq_handler_t irq_handler, unsigned long irq_flags, struct  
scsi_host_template * sht);
```

Arguments

host

target ATA host

irq

IRQ to request

irq_handler

irq_handler used when requesting IRQ

irq_flags

irq_flags used when requesting IRQ

sht

scsi_host_template to use when registering the host

Description

After allocating an ATA host and initializing it, most libata LLDs perform three steps to activate the host - start host, request IRQ and register it. This helper takes necessary arguments and performs the three steps in one go.

An invalid IRQ skips the IRQ registration and expects the host to have set polling mode on the port. In this case, *irq_handler* should be NULL.

LOCKING

Inherited from calling layer (may sleep).

RETURNS

0 on success, -errno otherwise.

ata_host_detach

LINUX

Kernel Hackers Manual February 2009

Name

`ata_host_detach` — Detach all ports of an ATA host

Synopsis

```
void ata_host_detach (struct ata_host * host);
```

Arguments

host

Host to detach

Description

Detach all ports of *host*.

LOCKING

Kernel thread context (may sleep).

ata_pci_remove_one

LINUX

Kernel Hackers Manual February 2009

Name

`ata_pci_remove_one` — PCI layer callback for device removal

Synopsis

```
void ata_pci_remove_one (struct pci_dev * pdev);
```

Arguments

pdev

PCI device that was removed

Description

PCI layer indicates to libata via this hook that hot-unplug or module unload event has occurred. Detach all ports. Resource release is handled via devres.

LOCKING

Inherited from PCI layer (may sleep).

ata_wait_register

LINUX

Kernel Hackers Manual February 2009

Name

`ata_wait_register` — wait until register value changes

Synopsis

```
u32 ata_wait_register (void __iomem * reg, u32 mask, u32 val,  
unsigned long interval, unsigned long timeout);
```

Arguments

reg

IO-mapped register

mask

Mask to apply to read register value

val

Wait condition

interval

polling interval in milliseconds

timeout

timeout in milliseconds

Description

Waiting for some bits of register to change is a common operation for ATA controllers. This function reads 32bit LE IO-mapped register *reg* and tests for the following condition.

```
(*reg & mask) != val
```

If the condition is met, it returns; otherwise, the process is repeated after *interval_msec* until timeout.

LOCKING

Kernel thread context (may sleep)

RETURNS

The final register value.

Chapter 5. libata Core Internals

ata_dev_phys_link

LINUX

Kernel Hackers Manual February 2009

Name

`ata_dev_phys_link` — find physical link for a device

Synopsis

```
struct ata_link * ata_dev_phys_link (struct ata_device * dev);
```

Arguments

dev

ATA device to look up physical link for

Description

Look up physical link which *dev* is attached to. Note that this is different from *dev->link* only when *dev* is on slave link. For all other cases, it's the same as *dev->link*.

LOCKING

Don't care.

RETURNS

Pointer to the found physical link.

ata_force_cbl

LINUX

Kernel Hackers Manual February 2009

Name

`ata_force_cbl` — force cable type according to `libata.force`

Synopsis

```
void ata_force_cbl (struct ata_port * ap);
```

Arguments

ap

ATA port of interest

Description

Force cable type according to `libata.force` and whine about it. The last entry which has matching port number is used, so it can be specified as part of device force parameters. For example, both “a:40c,1.00:udma4” and “1.00:40c,udma4” have the same effect.

LOCKING

EH context.

ata_force_link_limits

LINUX

Kernel Hackers Manual February 2009

Name

`ata_force_link_limits` — force link limits according to `libata.force`

Synopsis

```
void ata_force_link_limits (struct ata_link * link);
```

Arguments

link

ATA link of interest

Description

Force link flags and SATA spd limit according to `libata.force` and whine about it. When only the port part is specified (e.g. 1:), the limit applies to all links connected to both the host link and all fan-out ports connected via PMP. If the device part is specified as 0 (e.g. 1.00:), it specifies the first fan-out link not the host link. Device number 15 always points to the host link whether PMP is attached or not. If the controller has slave link, device number 16 points to it.

LOCKING

EH context.

ata_force_xfermask

LINUX

Kernel Hackers Manual February 2009

Name

`ata_force_xfermask` — force xfermask according to `libata.force`

Synopsis

```
void ata_force_xfermask (struct ata_device * dev);
```

Arguments

dev

ATA device of interest

Description

Force `xfer_mask` according to `libata.force` and whine about it. For consistency with link selection, device number 15 selects the first device connected to the host link.

LOCKING

EH context.

ata_force_horkage

LINUX

Kernel Hackers Manual February 2009

Name

`ata_force_horkage` — force horkage according to `libata.force`

Synopsis

```
void ata_force_horkage (struct ata_device * dev);
```

Arguments

dev

ATA device of interest

Description

Force horkage according to `libata.force` and whine about it. For consistency with link selection, device number 15 selects the first device connected to the host link.

LOCKING

EH context.

ata_rwcmd_protocol

LINUX

Kernel Hackers Manual February 2009

Name

`ata_rwcmd_protocol` — set taskfile r/w commands and protocol

Synopsis

```
int ata_rwcmd_protocol (struct ata_taskfile * tf, struct
ata_device * dev);
```

Arguments

tf

command to examine and configure

dev

device *tf* belongs to

Description

Examine the device configuration and *tf->flags* to calculate the proper read/write commands and protocol to use.

LOCKING

caller.

ata_tf_read_block

LINUX

Kernel Hackers Manual February 2009

Name

`ata_tf_read_block` — Read block address from ATA taskfile

Synopsis

```
u64 ata_tf_read_block (struct ata_taskfile * tf, struct
ata_device * dev);
```

Arguments

tf

ATA taskfile of interest

dev

ATA device *tf* belongs to

LOCKING

None.

Read block address from *tf*. This function can handle all three address formats - LBA, LBA48 and CHS. *tf*->protocol and flags select the address format to use.

RETURNS

Block address read from *tf*.

ata_build_rw_tf

LINUX

Kernel Hackers Manual February 2009

Name

`ata_build_rw_tf` — Build ATA taskfile for given read/write request

Synopsis

```
int ata_build_rw_tf (struct ata_taskfile * tf, struct
ata_device * dev, u64 block, u32 n_block, unsigned int
tf_flags, unsigned int tag);
```

Arguments

tf

Target ATA taskfile

dev

ATA device *tf* belongs to

block

Block address

n_block

Number of blocks

tf_flags

RW/FUA etc...

tag

tag

LOCKING

None.

Build ATA taskfile *tf* for read/write request described by *block*, *n_block*, *tf_flags* and *tag* on *dev*.

RETURNS

0 on success, -ERANGE if the request is too large for *dev*, -EINVAL if the request is invalid.

ata_dev_enable_pm

LINUX

Kernel Hackers Manual February 2009

Name

`ata_dev_enable_pm` — enable SATA interface power management

Synopsis

```
void ata_dev_enable_pm (struct ata_device * dev, enum link_pm  
policy);
```

Arguments

dev

device to enable power management

policy

the link power management policy

Description

Enable SATA Interface power management. This will enable Device Interface Power Management (DIPM) for min_power policy, and then call driver specific callbacks for enabling Host Initiated Power management.

Locking

Caller.

Returns

-EINVAL if IPM is not supported, 0 otherwise.

ata_dev_disable_pm

LINUX

Kernel Hackers Manual February 2009

Name

ata_dev_disable_pm — disable SATA interface power management

Synopsis

```
void ata_dev_disable_pm (struct ata_device * dev);
```


Arguments

dev

device to disable power management

Description

Disable SATA Interface power management. This will disable Device Interface Power Management (DIPM) without changing policy, call driver specific callbacks for disabling Host Initiated Power management.

Locking

Caller.

Returns

void

ata_read_native_max_address

LINUX

Kernel Hackers Manual February 2009

Name

`ata_read_native_max_address` — Read native max address

Synopsis

```
int ata_read_native_max_address (struct ata_device * dev, u64
* max_sectors);
```

Arguments

dev

target device

max_sectors

out parameter for the result native max address

Description

Perform an LBA48 or LBA28 native size query upon the device in question.

RETURNS

0 on success, -EACCES if command is aborted by the drive. -EIO on other errors.

ata_set_max_sectors

LINUX

Kernel Hackers Manual February 2009

Name

`ata_set_max_sectors` — Set max sectors

Synopsis

```
int ata_set_max_sectors (struct ata_device * dev, u64  
new_sectors);
```

Arguments

dev

target device

new_sectors

new max sectors value to set for the device

Description

Set max sectors of *dev* to *new_sectors*.

RETURNS

0 on success, -EACCES if command is aborted or denied (due to previous non-volatile SET_MAX) by the drive. -EIO on other errors.

ata_hpa_resize

LINUX

Kernel Hackers Manual February 2009

Name

`ata_hpa_resize` — Resize a device with an HPA set

Synopsis

```
int ata_hpa_resize (struct ata_device * dev);
```

Arguments

dev

Device to resize

Description

Read the size of an LBA28 or LBA48 disk with HPA features and resize it if required to the full size of the media. The caller must check the drive has the HPA feature set enabled.

RETURNS

0 on success, -errno on failure.

ata_dump_id

LINUX

Kernel Hackers Manual February 2009

Name

`ata_dump_id` — IDENTIFY DEVICE info debugging output

Synopsis

```
void ata_dump_id (const u16 * id);
```

Arguments

id

IDENTIFY DEVICE page to dump

Description

Dump selected 16-bit words from the given IDENTIFY DEVICE page.

LOCKING

caller.

ata_pio_queue_task

LINUX

Kernel Hackers Manual February 2009

Name

ata_pio_queue_task — Queue port_task

Synopsis

```
void ata_pio_queue_task (struct ata_port * ap, void * data,  
unsigned long delay);
```

Arguments

ap

The ata_port to queue port_task for

data

data for *fn* to use

delay

delay time in msec for workqueue function

Description

Schedule *fn(data)* for execution after *delay* jiffies using port_task. There is one port_task per port and it's the user(low level driver)'s responsibility to make sure that only one task is active at any given time.

libata core layer takes care of synchronization between port_task and EH.

ata_pio_queue_task may be ignored for EH synchronization.

LOCKING

Inherited from caller.

ata_port_flush_task

LINUX

Kernel Hackers Manual February 2009

Name

ata_port_flush_task — Flush port_task

Synopsis

```
void ata_port_flush_task (struct ata_port * ap);
```

Arguments

ap

The `ata_port` to flush `port_task` for

Description

After this function completes, `port_task` is guranteed not to be running or scheduled.

LOCKING

Kernel thread context (may sleep)

ata_exec_internal_sg

LINUX

Kernel Hackers Manual February 2009

Name

`ata_exec_internal_sg` — execute libata internal command

Synopsis

```
unsigned ata_exec_internal_sg (struct ata_device * dev, struct  
ata_taskfile * tf, const u8 * cdb, int dma_dir, struct
```

```
scatterlist * sgl, unsigned int n_elem, unsigned long
timeout);
```

Arguments

dev

Device to which the command is sent

tf

Taskfile registers for the command and the result

cdb

CDB for packet command

dma_dir

Data tranfer direction of the command

sgl

sg list for the data buffer of the command

n_elem

Number of sg entries

timeout

Timeout in msec (0 for default)

Description

Executes libata internal command with timeout. *tf* contains command on entry and result on return. Timeout and error conditions are reported via return value. No recovery action is taken after a command times out. It's caller's duty to clean up after timeout.

LOCKING

None. Should be called with kernel context, might sleep.

RETURNS

Zero on success, AC_ERR_* mask on failure

ata_exec_internal

LINUX

Kernel Hackers Manual February 2009

Name

`ata_exec_internal` — execute libata internal command

Synopsis

```
unsigned ata_exec_internal (struct ata_device * dev, struct  
ata_taskfile * tf, const u8 * cdb, int dma_dir, void * buf,  
unsigned int buflen, unsigned long timeout);
```

Arguments

dev

Device to which the command is sent

tf

Taskfile registers for the command and the result

cdb

CDB for packet command

dma_dir

Data transfer direction of the command

buf

Data buffer of the command

buflen

Length of data buffer

timeout

Timeout in msec (0 for default)

Description

Wrapper around `ata_exec_internal_sg` which takes simple buffer instead of sg list.

LOCKING

None. Should be called with kernel context, might sleep.

RETURNS

Zero on success, `AC_ERR_*` mask on failure

ata_do_simple_cmd

LINUX

Kernel Hackers Manual February 2009

Name

`ata_do_simple_cmd` — execute simple internal command

Synopsis

```
unsigned int ata_do_simple_cmd (struct ata_device * dev, u8  
cmd);
```

Arguments

dev

Device to which the command is sent

cmd

Opcode to execute

Description

Execute a 'simple' command, that only consists of the opcode 'cmd' itself, without filling any other registers

LOCKING

Kernel thread context (may sleep).

RETURNS

Zero on success, AC_ERR_* mask on failure

ata_pio_mask_no_iordy

LINUX

Name

`ata_pio_mask_no_iordy` — Return the non IORDY mask

Synopsis

```
u32 ata_pio_mask_no_iordy (const struct ata_device * adev);
```

Arguments

adev

ATA device

Description

Compute the highest mode possible if we are not using iordy. Return -1 if no iordy mode is available.

ata_dev_read_id

LINUX

Name

`ata_dev_read_id` — Read ID data from the specified device

Synopsis

```
int ata_dev_read_id (struct ata_device * dev, unsigned int *
p_class, unsigned int flags, u16 * id);
```

Arguments

dev

target device

p_class

pointer to class of the target device (may be changed)

flags

ATA_READID_* flags

id

buffer to read IDENTIFY data into

Description

Read ID data from the specified device. ATA_CMD_ID_ATA is performed on ATA devices and ATA_CMD_ID_ATAPI on ATAPI devices. This function also issues ATA_CMD_INIT_DEV_PARAMS for pre-ATA4 drives.

FIXME

ATA_CMD_ID_ATA is optional for early drives and right now we abort if we hit that case.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, -errno otherwise.

ata_dev_configure

LINUX

Kernel Hackers Manual February 2009

Name

`ata_dev_configure` — Configure the specified ATA/ATAPI device

Synopsis

```
int ata_dev_configure (struct ata_device * dev);
```

Arguments

dev

Target device to configure

Description

Configure *dev* according to *dev->id*. Generic and low-level driver specific fixups are also applied.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, -errno otherwise

ata_bus_probe

LINUX

Kernel Hackers Manual February 2009

Name

`ata_bus_probe` — Reset and probe ATA bus

Synopsis

```
int ata_bus_probe (struct ata_port * ap);
```

Arguments

ap

Bus to probe

Description

Master ATA bus probing function. Initiates a hardware-dependent bus reset, then attempts to identify any devices found on the bus.

LOCKING

PCI/etc. bus probe sem.

RETURNS

Zero on success, negative errno otherwise.

sata_print_link_status

LINUX

Kernel Hackers Manual February 2009

Name

`sata_print_link_status` — Print SATA link status

Synopsis

```
void sata_print_link_status (struct ata_link * link);
```

Arguments

link

SATA link to print link status about

Description

This function prints link speed and status of a SATA link.

LOCKING

None.

sata_down_spd_limit

LINUX

Kernel Hackers Manual February 2009

Name

`sata_down_spd_limit` — adjust SATA spd limit downward

Synopsis

```
int sata_down_spd_limit (struct ata_link * link);
```

Arguments

link

Link to adjust SATA spd limit for

Description

Adjust SATA spd limit of *link* downward. Note that this function only adjusts the limit. The change must be applied using `sata_set_spd`.

LOCKING

Inherited from caller.

RETURNS

0 on success, negative errno on failure

sata_set_spd_needed

LINUX

Kernel Hackers Manual February 2009

Name

`sata_set_spd_needed` — is SATA spd configuration needed

Synopsis

```
int sata_set_spd_needed (struct ata_link * link);
```

Arguments

link

Link in question

Description

Test whether the spd limit in SControl matches `link->sata_spd_limit`. This function is used to determine whether hardreset is necessary to apply SATA spd configuration.

LOCKING

Inherited from caller.

RETURNS

1 if SATA spd configuration is needed, 0 otherwise.

ata_down_xfermask_limit

LINUX

Kernel Hackers Manual February 2009

Name

`ata_down_xfermask_limit` — adjust dev xfer masks downward

Synopsis

```
int ata_down_xfermask_limit (struct ata_device * dev, unsigned
int sel);
```

Arguments

dev

Device to adjust xfer masks

sel

ATA_DNXFER_* selector

Description

Adjust xfer masks of *dev* downward. Note that this function does not apply the change. Invoking `ata_set_mode` afterwards will apply the limit.

LOCKING

Inherited from caller.

RETURNS

0 on success, negative errno on failure

ata_wait_ready

LINUX

Kernel Hackers Manual February 2009

Name

`ata_wait_ready` — wait for link to become ready

Synopsis

```
int ata_wait_ready (struct ata_link * link, unsigned long
deadline, int (*check_ready) (struct ata_link *link));
```

Arguments

link

link to be waited on

deadline

deadline jiffies for the operation

check_ready

callback to check link readiness

Description

Wait for *link* to become ready. *check_ready* should return positive number if *link* is ready, 0 if it isn't, -ENODEV if link doesn't seem to be occupied, other errno for other error conditions.

Transient -ENODEV conditions are allowed for ATA_TMOUT_FF_WAIT.

LOCKING

EH context.

RETURNS

0 if *linke* is ready before *deadline*; otherwise, -errno.

ata_dev_same_device

LINUX

Kernel Hackers Manual February 2009

Name

`ata_dev_same_device` — Determine whether new ID matches configured device

Synopsis

```
int ata_dev_same_device (struct ata_device * dev, unsigned int
new_class, const ul6 * new_id);
```

Arguments

dev

device to compare against

new_class

class of the new device

new_id

IDENTIFY page of the new device

Description

Compare *new_class* and *new_id* against *dev* and determine whether *dev* is the device indicated by *new_class* and *new_id*.

LOCKING

None.

RETURNS

1 if *dev* matches *new_class* and *new_id*, 0 otherwise.

ata_dev_reread_id

LINUX

Kernel Hackers Manual February 2009

Name

ata_dev_reread_id — Re-read IDENTIFY data

Synopsis

```
int ata_dev_reread_id (struct ata_device * dev, unsigned int  
readid_flags);
```

Arguments

dev

target ATA device

readid_flags

read ID flags

Description

Re-read IDENTIFY page and make sure *dev* is still attached to the port.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, negative errno otherwise

ata_dev_revalidate

LINUX

Name

`ata_dev_revalidate` — Revalidate ATA device

Synopsis

```
int ata_dev_revalidate (struct ata_device * dev, unsigned int
new_class, unsigned int readid_flags);
```

Arguments

dev

device to revalidate

new_class

new class code

readid_flags

read ID flags

Description

Re-read IDENTIFY page, make sure *dev* is still attached to the port and reconfigure it according to the new IDENTIFY page.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, negative errno otherwise

ata_is_40wire

LINUX

Kernel Hackers Manual February 2009

Name

`ata_is_40wire` — check drive side detection

Synopsis

```
int ata_is_40wire (struct ata_device * dev);
```

Arguments

dev

device

Description

Perform drive side detection decoding, allowing for device vendors who can't follow the documentation.

cable_is_40wire

LINUX

Name

`cable_is_40wire` — 40/80/SATA decider

Synopsis

```
int cable_is_40wire (struct ata_port * ap);
```

Arguments

ap

port to consider

Description

This function encapsulates the policy for speed management in one place. At the moment we don't cache the result but there is a good case for setting `ap->cbl` to the result when we are called with unknown cables (and figuring out if it impacts hotplug at all).

Return 1 if the cable appears to be 40 wire.

ata_dev_xfermask

LINUX

Name

`ata_dev_xfermask` — Compute supported xfermask of the given device

Synopsis

```
void ata_dev_xfermask (struct ata_device * dev);
```

Arguments

dev

Device to compute xfermask for

Description

Compute supported xfermask of *dev* and store it in *dev->*_mask*. This function is responsible for applying all known limits including host controller limits, device blacklist, etc...

LOCKING

None.

ata_dev_set_xfermode

LINUX

Kernel Hackers Manual February 2009

Name

`ata_dev_set_xfermode` — Issue SET FEATURES - XFER MODE command

Synopsis

```
unsigned int ata_dev_set_xfermode (struct ata_device * dev);
```

Arguments

dev

Device to which command will be sent

Description

Issue SET FEATURES - XFER MODE command to device *dev* on port *ap*.

LOCKING

PCI/etc. bus probe sem.

RETURNS

0 on success, AC_ERR_* mask otherwise.

ata_dev_set_feature

LINUX

Kernel Hackers Manual February 2009

Name

`ata_dev_set_feature` — Issue SET FEATURES - SATA FEATURES

Synopsis

```
unsigned int ata_dev_set_feature (struct ata_device * dev, u8
enable, u8 feature);
```

Arguments

dev

Device to which command will be sent

enable

Whether to enable or disable the feature

feature

The sector count represents the feature to set

Description

Issue SET FEATURES - SATA FEATURES command to device *dev* on port *ap* with sector count

LOCKING

PCI/etc. bus probe sem.

RETURNS

0 on success, AC_ERR_* mask otherwise.

ata_dev_init_params

LINUX

Kernel Hackers Manual February 2009

Name

`ata_dev_init_params` — Issue INIT DEV PARAMS command

Synopsis

```
unsigned int ata_dev_init_params (struct ata_device * dev, u16  
heads, u16 sectors);
```

Arguments

dev

Device to which command will be sent

heads

Number of heads (taskfile parameter)

sectors

Number of sectors (taskfile parameter)

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, `AC_ERR_*` mask otherwise.

ata_sg_clean

LINUX

Kernel Hackers Manual February 2009

Name

`ata_sg_clean` — Unmap DMA memory associated with command

Synopsis

```
void ata_sg_clean (struct ata_queued_cmd * qc);
```

Arguments

qc

Command containing DMA memory to be released

Description

Unmap all mapped DMA memory associated with this command.

LOCKING

`spin_lock_irqsave(host lock)`

atapi_check_dma

LINUX

Name

`ataapi_check_dma` — Check whether ATAPI DMA can be supported

Synopsis

```
int ataapi_check_dma (struct ata_queued_cmd * qc);
```

Arguments

qc

Metadata associated with taskfile to check

Description

Allow low-level driver to filter ATA PACKET commands, returning a status indicating whether or not it is OK to use DMA for the supplied PACKET command.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

0 when ATAPI DMA can be used nonzero otherwise

ata_sg_setup

LINUX

Kernel Hackers Manual February 2009

Name

`ata_sg_setup` — DMA-map the scatter-gather table associated with a command.

Synopsis

```
int ata_sg_setup (struct ata_queued_cmd * qc);
```

Arguments

qc

Command with scatter-gather table to be mapped.

Description

DMA-map the scatter-gather table associated with `queued_cmd` *qc*.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

Zero on success, negative on error.

swap_buf_le16

LINUX

Kernel Hackers Manual February 2009

Name

`swap_buf_le16` — swap halves of 16-bit words in place

Synopsis

```
void swap_buf_le16 (u16 * buf, unsigned int buf_words);
```

Arguments

buf

Buffer to swap

buf_words

Number of 16-bit words in buffer.

Description

Swap halves of 16-bit words if needed to convert from little-endian byte order to native cpu byte order, or vice-versa.

LOCKING

Inherited from caller.

ata_qc_new

LINUX

Kernel Hackers Manual February 2009

Name

`ata_qc_new` — Request an available ATA command, for queueing

Synopsis

```
struct ata_queued_cmd * ata_qc_new (struct ata_port * ap);
```

Arguments

ap

Port associated with device *dev*

LOCKING

None.

ata_qc_new_init

LINUX

Kernel Hackers Manual February 2009

Name

`ata_qc_new_init` — Request an available ATA command, and initialize it

Synopsis

```
struct ata_queued_cmd * ata_qc_new_init (struct ata_device *  
dev);
```

Arguments

dev

Device from whom we request an available command structure

LOCKING

None.

ata_qc_free

LINUX

Kernel Hackers Manual February 2009

Name

`ata_qc_free` — free unused `ata_queued_cmd`

Synopsis

```
void ata_qc_free (struct ata_queued_cmd * qc);
```

Arguments

qc

Command to complete

Description

Designed to free unused `ata_queued_cmd` object in case something prevents using it.

LOCKING

`spin_lock_irqsave(host lock)`

ata_qc_issue

LINUX

Kernel Hackers Manual February 2009

Name

`ata_qc_issue` — issue taskfile to device

Synopsis

```
void ata_qc_issue (struct ata_queued_cmd * qc);
```

Arguments

qc

command to issue to device

Description

Prepare an ATA command to submission to device. This includes mapping the data into a DMA-able area, filling in the S/G table, and finally writing the taskfile to hardware, starting the command.

LOCKING

spin_lock_irqsave(host lock)

ata_phys_link_online

LINUX

Kernel Hackers Manual February 2009

Name

`ata_phys_link_online` — test whether the given link is online

Synopsis

```
bool ata_phys_link_online (struct ata_link * link);
```

Arguments

link

ATA link to test

Description

Test whether *link* is online. Note that this function returns 0 if online status of *link* cannot be obtained, so `ata_link_online(link) != !ata_link_offline(link)`.

LOCKING

None.

RETURNS

True if the port online status is available and online.

ata_phys_link_offline

LINUX

Kernel Hackers Manual February 2009

Name

`ata_phys_link_offline` — test whether the given link is offline

Synopsis

```
bool ata_phys_link_offline (struct ata_link * link);
```

Arguments

link

ATA link to test

Description

Test whether *link* is offline. Note that this function returns 0 if offline status of *link* cannot be obtained, so `ata_link_online(link) != !ata_link_offline(link)`.

LOCKING

None.

RETURNS

True if the port offline status is available and offline.

ata_dev_init

LINUX

Kernel Hackers Manual February 2009

Name

`ata_dev_init` — Initialize an `ata_device` structure

Synopsis

```
void ata_dev_init (struct ata_device * dev);
```


Arguments

dev

Device structure to initialize

Description

Initialize *dev* in preparation for probing.

LOCKING

Inherited from caller.

ata_link_init

LINUX

Kernel Hackers Manual February 2009

Name

`ata_link_init` — Initialize an `ata_link` structure

Synopsis

```
void ata_link_init (struct ata_port * ap, struct ata_link *  
link, int pmp);
```

Arguments

ap

ATA port link is attached to

link

Link structure to initialize

pmp

Port multiplier port number

Description

Initialize *link*.

LOCKING

Kernel thread context (may sleep)

sata_link_init_spd

LINUX

Kernel Hackers Manual February 2009

Name

sata_link_init_spd — Initialize link->sata_spd_limit

Synopsis

```
int sata_link_init_spd (struct ata_link * link);
```

Arguments

link

Link to configure sata_spd_limit for

Description

Initialize *link*->[hw_]sata_spd_limit to the currently configured value.

LOCKING

Kernel thread context (may sleep).

RETURNS

0 on success, -errno on failure.

ata_port_alloc

LINUX

Kernel Hackers Manual February 2009

Name

`ata_port_alloc` — allocate and initialize basic ATA port resources

Synopsis

```
struct ata_port * ata_port_alloc (struct ata_host * host);
```

Arguments

host

ATA host this allocated port belongs to

Description

Allocate and initialize basic ATA port resources.

RETURNS

Allocate ATA port on success, NULL on failure.

LOCKING

Inherited from calling layer (may sleep).

ata_finalize_port_ops

LINUX

Kernel Hackers Manual February 2009

Name

`ata_finalize_port_ops` — finalize ata_port_operations

Synopsis

```
void ata_finalize_port_ops (struct ata_port_operations * ops);
```

Arguments

ops

ata_port_operations to finalize

Description

An ata_port_operations can inherit from another ops and that ops can again inherit from another. This can go on as many times as necessary as long as there is no loop in the inheritance chain.

Ops tables are finalized when the host is started. NULL or unspecified entries are inherited from the closet ancestor which has the method and the entry is populated with it. After finalization, the ops table directly points to all the methods and ->inherits is no longer necessary and cleared.

Using ATA_OP_NULL, inheriting ops can force a method to NULL.

LOCKING

None.

ata_port_detach

LINUX

Kernel Hackers Manual February 2009

Name

ata_port_detach — Detach ATA port in prepration of device removal

Synopsis

```
void ata_port_detach (struct ata_port * ap);
```

Arguments

ap

ATA port to be detached

Description

Detach all ATA devices and the associated SCSI devices of *ap*; then, remove the associated SCSI host. *ap* is guaranteed to be quiescent on return from this function.

LOCKING

Kernel thread context (may sleep).

Chapter 6. libata SCSI translation/emulation

ata_std_bios_param

LINUX

Kernel Hackers Manual February 2009

Name

`ata_std_bios_param` — generic bios head/sector/cylinder calculator used by sd.

Synopsis

```
int ata_std_bios_param (struct scsi_device * sdev, struct
block_device * bdev, sector_t capacity, int geom[]);
```

Arguments

sdev

SCSI device for which BIOS geometry is to be determined

bdev

block device associated with *sdev*

capacity

capacity of SCSI device

geom[]

location to which geometry will be output

Description

Generic bios head/sector/cylinder calculator used by sd. Most BIOSes nowadays expect a XXX/255/16 (CHS) mapping. Some situations may arise where the disk is not bootable if this is not used.

LOCKING

Defined by the SCSI layer. We don't really care.

RETURNS

Zero.

ata_scsi_slave_config

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsi_slave_config` — Set SCSI device attributes

Synopsis

```
int ata_scsi_slave_config (struct scsi_device * sdev);
```

Arguments

sdev

SCSI device to examine

Description

This is called before we actually start reading and writing to the device, to configure certain SCSI mid-layer behaviors.

LOCKING

Defined by SCSI layer. We don't really care.

ata_scsi_slave_destroy

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsi_slave_destroy` — SCSI device is about to be destroyed

Synopsis

```
void ata_scsi_slave_destroy (struct scsi_device * sdev);
```

Arguments

sdev

SCSI device to be destroyed

Description

sdev is about to be destroyed for hot/warm unplugging. If this unplugging was initiated by libata as indicated by `NULL dev->sdev`, this function doesn't have to do

anything. Otherwise, SCSI layer initiated warm-unplug is in progress. Clear dev->sdev, schedule the device for ATA detach and invoke EH.

LOCKING

Defined by SCSI layer. We don't really care.

ata_scsi_change_queue_depth

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsi_change_queue_depth` — SCSI callback for queue depth config

Synopsis

```
int ata_scsi_change_queue_depth (struct scsi_device * sdev,
int queue_depth);
```

Arguments

sdev

SCSI device to configure queue depth for

queue_depth

new queue depth

Description

This is libata standard `hostt->change_queue_depth` callback. SCSI will call into this callback when user tries to set queue depth via `sysfs`.

LOCKING

SCSI layer (we don't care)

RETURNS

Newly configured queue depth.

ata_scsi_queuecmd

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsi_queuecmd` — Issue SCSI cdb to libata-managed device

Synopsis

```
int ata_scsi_queuecmd (struct scsi_cmnd * cmd, void (*done)
(struct scsi_cmnd *));
```

Arguments

cmd

SCSI command to be sent

done

Completion function, called when command is complete

Description

In some cases, this function translates SCSI commands into ATA taskfiles, and queues the taskfiles to be sent to hardware. In other cases, this function simulates a SCSI device by evaluating and responding to certain SCSI commands. This creates the overall effect of ATA and ATAPI devices appearing as SCSI devices.

LOCKING

Releases scsi-layer-held lock, and obtains host lock.

RETURNS

Return value from `__ata_scsi_queuecmd` if *cmd* can be queued, 0 otherwise.

ata_scsi_simulate

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsi_simulate` — simulate SCSI command on ATA device

Synopsis

```
void ata_scsi_simulate (struct ata_device * dev, struct
scsi_cmnd * cmd, void (*done) (struct scsi_cmnd *));
```

Arguments

dev

the target device

cmd

SCSI command being sent to device.

done

SCSI command completion function.

Description

Interprets and directly executes a select list of SCSI commands that can be handled internally.

LOCKING

spin_lock_irqsave(host lock)

ata_sas_port_alloc

LINUX

Kernel Hackers Manual February 2009

Name

ata_sas_port_alloc — Allocate port for a SAS attached SATA device

Synopsis

```
struct ata_port * ata_sas_port_alloc (struct ata_host * host,  
struct ata_port_info * port_info, struct Scsi_Host * shost);
```

Arguments

host

ATA host container for all SAS ports

port_info

Information from low-level host driver

shost

SCSI host that the scsi device is attached to

LOCKING

PCI/etc. bus probe sem.

RETURNS

ata_port pointer on success / NULL on failure.

ata_sas_port_start

LINUX

Kernel Hackers Manual February 2009

Name

ata_sas_port_start — Set port up for dma.

Synopsis

```
int ata_sas_port_start (struct ata_port * ap);
```

Arguments

ap

Port to initialize

Description

Called just after data structures for each port are initialized.

May be used as the `port_start` entry in `ata_port_operations`.

LOCKING

Inherited from caller.

ata_sas_port_stop

LINUX

Kernel Hackers Manual February 2009

Name

`ata_sas_port_stop` — Undo `ata_sas_port_start`

Synopsis

```
void ata_sas_port_stop (struct ata_port * ap);
```

Arguments

ap

Port to shut down

Description

May be used as the `port_stop` entry in `ata_port_operations`.

LOCKING

Inherited from caller.

ata_sas_port_init

LINUX

Kernel Hackers Manual February 2009

Name

`ata_sas_port_init` — Initialize a SATA device

Synopsis

```
int ata_sas_port_init (struct ata_port * ap);
```


Arguments

ap

SATA port to initialize

LOCKING

PCI/etc. bus probe sem.

RETURNS

Zero on success, non-zero on error.

ata_sas_port_destroy

LINUX

Kernel Hackers Manual February 2009

Name

`ata_sas_port_destroy` — Destroy a SATA port allocated by `ata_sas_port_alloc`

Synopsis

```
void ata_sas_port_destroy (struct ata_port * ap);
```

Arguments

ap

SATA port to destroy

ata_sas_slave_configure

LINUX

Kernel Hackers ManualFebruary 2009

Name

ata_sas_slave_configure — Default slave_config routine for libata devices

Synopsis

```
int ata_sas_slave_configure (struct scsi_device * sdev, struct  
ata_port * ap);
```

Arguments

sdev

SCSI device to configure

ap

ATA port to which SCSI device is attached

RETURNS

Zero.

ata_sas_queuecmd

LINUX

Kernel Hackers Manual February 2009

Name

`ata_sas_queuecmd` — Issue SCSI cdb to libata-managed device

Synopsis

```
int ata_sas_queuecmd (struct scsi_cmnd * cmd, void (*done)
(struct scsi_cmnd *), struct ata_port * ap);
```

Arguments

cmd

SCSI command to be sent

done

Completion function, called when command is complete

ap

ATA port to which the command is being sent

RETURNS

Return value from `__ata_scsi_queuecmd` if *cmd* can be queued, 0 otherwise.

ata_get_identity

LINUX

Kernel Hackers Manual February 2009

Name

`ata_get_identity` — Handler for HDIO_GET_IDENTITY ioctl

Synopsis

```
int ata_get_identity (struct scsi_device * sdev, void __user *  
arg);
```

Arguments

sdev

SCSI device to get identify data for

arg

User buffer area for identify data

LOCKING

Defined by the SCSI layer. We don't really care.

RETURNS

Zero on success, negative errno on error.

ata_cmd_ioctl

LINUX

Kernel Hackers Manual February 2009

Name

`ata_cmd_ioctl` — Handler for HDIO_DRIVE_CMD ioctl

Synopsis

```
int ata_cmd_ioctl (struct scsi_device * scsidev, void __user *  
arg);
```

Arguments

scsidev

Device to which we are issuing command

arg

User provided data for issuing command

LOCKING

Defined by the SCSI layer. We don't really care.

RETURNS

Zero on success, negative errno on error.

ata_task_ioctl

LINUX

Kernel Hackers Manual February 2009

Name

`ata_task_ioctl` — Handler for HDIO_DRIVE_TASK ioctl

Synopsis

```
int ata_task_ioctl (struct scsi_device * scsidev, void __user  
* arg);
```

Arguments

scsidev

Device to which we are issuing command

arg

User provided data for issuing command

LOCKING

Defined by the SCSI layer. We don't really care.

RETURNS

Zero on success, negative errno on error.

ata_scsi_qc_new

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsi_qc_new` — acquire new `ata_queued_cmd` reference

Synopsis

```
struct ata_queued_cmd * ata_scsi_qc_new (struct ata_device *  
dev, struct scsi_cmnd * cmd, void (*done) (struct scsi_cmnd  
*)) ;
```

Arguments

dev

ATA device to which the new command is attached

cmd

SCSI command that originated this ATA command

done

SCSI command completion function

Description

Obtain a reference to an unused `ata_queued_cmd` structure, which is the basic libata structure representing a single ATA command sent to the hardware.

If a command was available, fill in the SCSI-specific portions of the structure with information on the current command.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

Command allocated, or `NULL` if none available.

ata_dump_status

LINUX

Kernel Hackers Manual February 2009

Name

`ata_dump_status` — user friendly display of error info

Synopsis

```
void ata_dump_status (unsigned id, struct ata_taskfile * tf);
```

Arguments

id

id of the port in question

tf

ptr to filled out taskfile

Description

Decode and dump the ATA error/status registers for the user so that they have some idea what really happened at the non make-believe layer.

LOCKING

inherited from caller

ata_to_sense_error

LINUX

Kernel Hackers Manual February 2009

Name

`ata_to_sense_error` — convert ATA error to SCSI error

Synopsis

```
void ata_to_sense_error (unsigned id, u8 drv_stat, u8 drv_err,  
u8 * sk, u8 * asc, u8 * ascq, int verbose);
```

Arguments

id

ATA device number

drv_stat

value contained in ATA status register

drv_err

value contained in ATA error register

sk

the sense key we'll fill out

asc

the additional sense code we'll fill out

ascq

the additional sense code qualifier we'll fill out

verbose

be verbose

Description

Converts an ATA error into a SCSI error. Fill out pointers to SK, ASC, and ASCQ bytes for later use in fixed or descriptor format sense blocks.

LOCKING

spin_lock_irqsave(host lock)

ata_gen_ata_sense

LINUX

Kernel Hackers Manual February 2009

Name

ata_gen_ata_sense — generate a SCSI fixed sense block

Synopsis

```
void ata_gen_ata_sense (struct ata_queued_cmd * qc);
```

Arguments

qc

Command that we are erroring out

Description

Generate sense block for a failed ATA command *qc*. Descriptor format is used to accomodate LBA48 block address.

LOCKING

None.

atapi_drain_needed

LINUX

Kernel Hackers Manual February 2009

Name

`atapi_drain_needed` — Check whether data transfer may overflow

Synopsis

```
int atapi_drain_needed (struct request * rq);
```

Arguments

rq

request to be checked

Description

ATAPI commands which transfer variable length data to host might overflow due to application error or hardware bug. This function checks whether overflow should be drained and ignored for *request*.

LOCKING

None.

RETURNS

1 if ; otherwise, 0.

ata_scsi_start_stop_xlat

LINUX

Kernel Hackers Manual February 2009

Name

ata_scsi_start_stop_xlat — Translate SCSI START STOP UNIT command

Synopsis

```
unsigned int ata_scsi_start_stop_xlat (struct ata_queued_cmd *  
qc);
```

Arguments

qc

Storage for translated ATA taskfile

Description

Sets up an ATA taskfile to issue STANDBY (to stop) or READ VERIFY (to start). Perhaps these commands should be preceded by CHECK POWER MODE to see what power mode the device is already in. [See SAT revision 5 at www.t10.org]

LOCKING

spin_lock_irqsave(host lock)

RETURNS

Zero on success, non-zero on error.

ata_scsi_flush_xlat

LINUX

Name

`ata_scsi_flush_xlat` — Translate SCSI SYNCHRONIZE CACHE command

Synopsis

```
unsigned int ata_scsi_flush_xlat (struct ata_queued_cmd * qc);
```

Arguments

qc

Storage for translated ATA taskfile

Description

Sets up an ATA taskfile to issue FLUSH CACHE or FLUSH CACHE EXT.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

Zero on success, non-zero on error.

scsi_6_lba_len

LINUX

Kernel Hackers Manual February 2009

Name

`scsi_6_lba_len` — Get LBA and transfer length

Synopsis

```
void scsi_6_lba_len (const u8 * cdb, u64 * plba, u32 * plen);
```

Arguments

cdb

SCSI command to translate

plba

the LBA

plen

the transfer length

Description

Calculate LBA and transfer length for 6-byte commands.

scsi_10_lba_len

LINUX

Kernel Hackers Manual February 2009

Name

`scsi_10_lba_len` — Get LBA and transfer length

Synopsis

```
void scsi_10_lba_len (const u8 * cdb, u64 * plba, u32 * plen);
```

Arguments

cdb

SCSI command to translate

plba

the LBA

plen

the transfer length

Description

Calculate LBA and transfer length for 10-byte commands.

scsi_16_lba_len

LINUX

Kernel Hackers Manual February 2009

Name

`scsi_16_lba_len` — Get LBA and transfer length

Synopsis

```
void scsi_16_lba_len (const u8 * cdb, u64 * plba, u32 * plen);
```

Arguments

cdb

SCSI command to translate

plba

the LBA

plen

the transfer length

Description

Calculate LBA and transfer length for 16-byte commands.

ata_scsi_verify_xlat

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsi_verify_xlat` — Translate SCSI VERIFY command into an ATA one

Synopsis

```
unsigned int ata_scsi_verify_xlat (struct ata_queued_cmd *  
qc);
```

Arguments

qc

Storage for translated ATA taskfile

Description

Converts SCSI VERIFY command to an ATA READ VERIFY command.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

Zero on success, non-zero on error.

ata_scsi_rw_xlat

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsi_rw_xlat` — Translate SCSI r/w command into an ATA one

Synopsis

```
unsigned int ata_scsi_rw_xlat (struct ata_queued_cmd * qc);
```

Arguments

qc

Storage for translated ATA taskfile

Description

Converts any of six SCSI read/write commands into the ATA counterpart, including starting sector (LBA), sector count, and taking into account the device's LBA48 support.

Commands `READ_6`, `READ_10`, `READ_16`, `WRITE_6`, `WRITE_10`, and `WRITE_16` are currently supported.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

Zero on success, non-zero on error.

ata_scsi_translate

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsi_translate` — Translate then issue SCSI command to ATA device

Synopsis

```
int ata_scsi_translate (struct ata_device * dev, struct
scsi_cmnd * cmd, void (*done) (struct scsi_cmnd *),
ata_xlat_func_t xlat_func);
```

Arguments

dev

ATA device to which the command is addressed

cmd

SCSI command to execute

done

SCSI command completion function

xlat_func

Actor which translates *cmd* to an ATA taskfile

Description

Our `->queuecommand` function has decided that the SCSI command issued can be directly translated into an ATA command, rather than handled internally.

This function sets up an `ata_queued_cmd` structure for the SCSI command, and sends that `ata_queued_cmd` to the hardware.

The `xlat_func` argument (actor) returns 0 if ready to execute ATA command, else 1 to finish translation. If 1 is returned then `cmd->result` (and possibly `cmd->sense_buffer`) are assumed to be set reflecting an error condition or clean (early) termination.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

0 on success, `SCSI_ML_QUEUE_DEVICE_BUSY` if the command needs to be deferred.

ata_scsi_rbuf_get

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsi_rbuf_get` — Map response buffer.

Synopsis

```
void * ata_scsi_rbuf_get (struct scsi_cmnd * cmd, bool
copy_in, unsigned long * flags);
```

Arguments

cmd

SCSI command containing buffer to be mapped.

copy_in

copy in from user buffer

flags

unsigned long variable to store irq enable status

Description

Prepare buffer for simulated SCSI commands.

LOCKING

spin_lock_irqsave(ata_scsi_rbuf_lock) on success

RETURNS

Pointer to response buffer.

ata_scsi_rbuf_put

LINUX

Kernel Hackers Manual February 2009

Name

ata_scsi_rbuf_put — Unmap response buffer.

Synopsis

```
void ata_scsi_rbuf_put (struct scsi_cmnd * cmd, bool copy_out,  
unsigned long * flags);
```

Arguments

cmd

SCSI command containing buffer to be unmapped.

copy_out

copy out result

flags

flags passed to `ata_scsi_rbuf_get`

Description

Returns rbuf buffer. The result is copied to *cmd*'s buffer if *copy_back* is true.

LOCKING

Unlocks `ata_scsi_rbuf_lock`.

ata_scsi_rbuf_fill

LINUX

Name

`ata_scsi_rbuf_fill` — wrapper for SCSI command simulators

Synopsis

```
void ata_scsi_rbuf_fill (struct ata_scsi_args * args, unsigned
int (*actor) (struct ata_scsi_args *args, u8 *rbuf));
```

Arguments

args

device IDENTIFY data / SCSI command of interest.

actor

Callback hook for desired SCSI command simulator

Description

Takes care of the hard work of simulating a SCSI command... Mapping the response buffer, calling the command's handler, and handling the handler's return value. This return value indicates whether the handler wishes the SCSI command to be completed successfully (0), or not (in which case `cmd->result` and sense buffer are assumed to be set).

LOCKING

`spin_lock_irqsave(host lock)`

ata_scsiop_inq_std

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsiop_inq_std` — Simulate INQUIRY command

Synopsis

```
unsigned int ata_scsiop_inq_std (struct ata_scsi_args * args,  
u8 * rbuf);
```

Arguments

args

device IDENTIFY data / SCSI command of interest.

rbuf

Response buffer, to which simulated SCSI cmd output is sent.

Description

Returns standard device identification data associated with non-VPD INQUIRY command output.

LOCKING

`spin_lock_irqsave(host lock)`

ata_scsiop_inq_00

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsiop_inq_00` — Simulate INQUIRY VPD page 0, list of pages

Synopsis

```
unsigned int ata_scsiop_inq_00 (struct ata_scsi_args * args,  
u8 * rbuf);
```

Arguments

args

device IDENTIFY data / SCSI command of interest.

rbuf

Response buffer, to which simulated SCSI cmd output is sent.

Description

Returns list of inquiry VPD pages available.

LOCKING

`spin_lock_irqsave(host lock)`

ata_scsiop_inq_80

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsiop_inq_80` — Simulate INQUIRY VPD page 80, device serial number

Synopsis

```
unsigned int ata_scsiop_inq_80 (struct ata_scsi_args * args,  
u8 * rbuf);
```

Arguments

args

device IDENTIFY data / SCSI command of interest.

rbuf

Response buffer, to which simulated SCSI cmd output is sent.

Description

Returns ATA device serial number.

LOCKING

`spin_lock_irqsave(host lock)`

ata_scsiop_inq_83

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsiop_inq_83` — Simulate INQUIRY VPD page 83, device identity

Synopsis

```
unsigned int ata_scsiop_inq_83 (struct ata_scsi_args * args,  
u8 * rbuf);
```

Arguments

args

device IDENTIFY data / SCSI command of interest.

rbuf

Response buffer, to which simulated SCSI cmd output is sent.

Yields two logical unit device identification designators

- vendor specific ASCII containing the ATA serial number - SAT defined “t10 vendor id based” containing ASCII vendor name (“ATA ”), model and serial numbers.

LOCKING

`spin_lock_irqsave(host lock)`

ata_scsiop_inq_89

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsiop_inq_89` — Simulate INQUIRY VPD page 89, ATA info

Synopsis

```
unsigned int ata_scsiop_inq_89 (struct ata_scsi_args * args,  
u8 * rbuf);
```

Arguments

args

device IDENTIFY data / SCSI command of interest.

rbuf

Response buffer, to which simulated SCSI cmd output is sent.

Description

Yields SAT-specified ATA VPD page.

LOCKING

`spin_lock_irqsave(host lock)`

ata_scsiop_noop

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsiop_noop` — Command handler that simply returns success.

Synopsis

```
unsigned int ata_scsiop_noop (struct ata_scsi_args * args, u8  
* rbuf);
```

Arguments

args

device IDENTIFY data / SCSI command of interest.

rbuf

Response buffer, to which simulated SCSI cmd output is sent.

Description

No operation. Simply returns success to caller, to indicate that the caller should successfully complete this SCSI command.

LOCKING

`spin_lock_irqsave(host lock)`

ata_msense_caching

LINUX

Kernel Hackers Manual February 2009

Name

`ata_msense_caching` — Simulate MODE SENSE caching info page

Synopsis

```
unsigned int ata_msense_caching (u16 * id, u8 * buf);
```

Arguments

id

device IDENTIFY data

buf

output buffer

Description

Generate a caching info page, which conditionally indicates write caching to the SCSI layer, depending on device capabilities.

LOCKING

None.

ata_msense_ctl_mode

LINUX

Kernel Hackers Manual February 2009

Name

`ata_msense_ctl_mode` — Simulate MODE SENSE control mode page

Synopsis

```
unsigned int ata_msense_ctl_mode (u8 * buf);
```

Arguments

buf

output buffer

Description

Generate a generic MODE SENSE control mode page.

LOCKING

None.

ata_msense_rw_recovery

LINUX

Name

`ata_msense_rw_recovery` — Simulate MODE SENSE r/w error recovery page

Synopsis

```
unsigned int ata_msense_rw_recovery (u8 * buf);
```

Arguments

buf

output buffer

Description

Generate a generic MODE SENSE r/w error recovery page.

LOCKING

None.

`ata_scsiop_mode_sense`

LINUX

Name

`ata_scsiop_mode_sense` — Simulate MODE SENSE 6, 10 commands

Synopsis

```
unsigned int ata_scsiop_mode_sense (struct ata_scsi_args *  
args, u8 * rbuf);
```

Arguments

args

device IDENTIFY data / SCSI command of interest.

rbuf

Response buffer, to which simulated SCSI cmd output is sent.

Description

Simulate MODE SENSE commands. Assume this is invoked for direct access devices (e.g. disks) only. There should be no block descriptor for other device types.

LOCKING

`spin_lock_irqsave(host lock)`

ata_scsiop_read_cap

LINUX

Name

`ata_scsiop_read_cap` — Simulate READ CAPACITY[16] commands

Synopsis

```
unsigned int ata_scsiop_read_cap (struct ata_scsi_args * args,  
u8 * rbuf);
```

Arguments

args

device IDENTIFY data / SCSI command of interest.

rbuf

Response buffer, to which simulated SCSI cmd output is sent.

Description

Simulate READ CAPACITY commands.

LOCKING

None.

`ata_scsiop_report_luns`

LINUX

Name

`ata_scsiop_report_luns` — Simulate REPORT LUNS command

Synopsis

```
unsigned int ata_scsiop_report_luns (struct ata_scsi_args *  
args, u8 * rbuf);
```

Arguments

args

device IDENTIFY data / SCSI command of interest.

rbuf

Response buffer, to which simulated SCSI cmd output is sent.

Description

Simulate REPORT LUNS command.

LOCKING

`spin_lock_irqsave(host lock)`

atapi_xlat

LINUX

Name

`ata_pi_xlat` — Initialize PACKET taskfile

Synopsis

```
unsigned int ata_pi_xlat (struct ata_queued_cmd * qc);
```

Arguments

qc
command structure to be initialized

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

Zero on success, non-zero on failure.

`ata_scsi_find_dev`

LINUX

Name

`ata_scsi_find_dev` — lookup `ata_device` from `scsi_cmnd`

Synopsis

```
struct ata_device * ata_scsi_find_dev (struct ata_port * ap,  
const struct scsi_device * scsidev);
```

Arguments

ap

ATA port to which the device is attached

scsidev

SCSI device from which we derive the ATA device

Description

Given various information provided in struct `scsi_cmnd`, map that onto an ATA bus, and using that mapping determine which `ata_device` is associated with the SCSI command to be sent.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

Associated ATA device, or `NULL` if not found.

ata_scsi_pass_thru

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsi_pass_thru` — convert ATA pass-thru CDB to taskfile

Synopsis

```
unsigned int ata_scsi_pass_thru (struct ata_queued_cmd * qc);
```

Arguments

qc

command structure to be initialized

Description

Handles either 12 or 16-byte versions of the CDB.

RETURNS

Zero on success, non-zero on failure.

ata_get_xlat_func

LINUX

Name

`ata_get_xlat_func` — check if SCSI to ATA translation is possible

Synopsis

```
ata_xlat_func_t ata_get_xlat_func (struct ata_device * dev, u8  
cmd);
```

Arguments

dev

ATA device

cmd

SCSI command opcode to consider

Description

Look up the SCSI command given, and determine whether the SCSI command is to be translated or simulated.

RETURNS

Pointer to translation function if possible, `NULL` if not.

ata_scsi_dump_cdb

LINUX

Name

`ata_scsi_dump_cdb` — dump SCSI command contents to dmesg

Synopsis

```
void ata_scsi_dump_cdb (struct ata_port * ap, struct scsi_cmnd  
* cmd);
```

Arguments

ap

ATA port to which the command was being sent

cmd

SCSI command to dump

Description

Prints the contents of a SCSI command via `printk`.

ata_scsi_offline_dev

LINUX

Name

`ata_scsi_offline_dev` — offline attached SCSI device

Synopsis

```
int ata_scsi_offline_dev (struct ata_device * dev);
```

Arguments

dev

ATA device to offline attached SCSI device for

Description

This function is called from `ata_eh_hotplug` and responsible for taking the SCSI device attached to *dev* offline. This function is called with host lock which protects `dev->sdev` against clearing.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

1 if attached SCSI device exists, 0 otherwise.

ata_scsi_remove_dev

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsi_remove_dev` — remove attached SCSI device

Synopsis

```
void ata_scsi_remove_dev (struct ata_device * dev);
```

Arguments

dev

ATA device to remove attached SCSI device for

Description

This function is called from `ata_eh_scsi_hotplug` and responsible for removing the SCSI device attached to *dev*.

LOCKING

Kernel thread context (may sleep).

ata_scsi_media_change_notify

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsi_media_change_notify` — send media change event

Synopsis

```
void ata_scsi_media_change_notify (struct ata_device * dev);
```

Arguments

dev

Pointer to the disk device with media change event

Description

Tell the block layer to send a media change notification event.

LOCKING

spin_lock_irqsave(host lock)

ata_scsi_hotplug

LINUX

Kernel Hackers Manual February 2009

Name

ata_scsi_hotplug — SCSI part of hotplug

Synopsis

```
void ata_scsi_hotplug (struct work_struct * work);
```

Arguments

work

Pointer to ATA port to perform SCSI hotplug on

Description

Perform SCSI part of hotplug. It's executed from a separate workqueue after EH completes. This is necessary because SCSI hot plugging requires working EH and hot unplugging is synchronized with hot plugging with a mutex.

LOCKING

Kernel thread context (may sleep).

ata_scsi_user_scan

LINUX

Kernel Hackers Manual February 2009

Name

`ata_scsi_user_scan` — indication for user-initiated bus scan

Synopsis

```
int ata_scsi_user_scan (struct Scsi_Host * shost, unsigned int
channel, unsigned int id, unsigned int lun);
```

Arguments

shost

SCSI host to scan

channel

Channel to scan

id

ID to scan

lun

LUN to scan

Description

This function is called when user explicitly requests bus scan. Set probe pending flag and invoke EH.

LOCKING

SCSI layer (we don't care)

RETURNS

Zero.

ata_scsi_dev_rescan

LINUX

Name

`ata_scsi_dev_rescan` — initiate `scsi_rescan_device`

Synopsis

```
void ata_scsi_dev_rescan (struct work_struct * work);
```

Arguments

work

Pointer to ATA port to perform `scsi_rescan_device`

Description

After ATA pass thru (SAT) commands are executed successfully, libata need to propagate the changes to SCSI layer. This function must be executed from `ata_aux_wq` such that `sdev attach/detach` don't race with `rescan`.

LOCKING

Kernel thread context (may sleep).

Chapter 7. ATA errors and exceptions

This chapter tries to identify what error/exception conditions exist for ATA/ATAPI devices and describe how they should be handled in implementation-neutral way.

The term 'error' is used to describe conditions where either an explicit error condition is reported from device or a command has timed out.

The term 'exception' is either used to describe exceptional conditions which are not errors (say, power or hotplug events), or to describe both errors and non-error exceptional conditions. Where explicit distinction between error and exception is necessary, the term 'non-error exception' is used.

7.1. Exception categories

Exceptions are described primarily with respect to legacy taskfile + bus master IDE interface. If a controller provides other better mechanism for error reporting, mapping those into categories described below shouldn't be difficult.

In the following sections, two recovery actions - reset and reconfiguring transport - are mentioned. These are described further in Section 7.2.

7.1.1. HSM violation

This error is indicated when STATUS value doesn't match HSM requirement during issuing or execution any ATA/ATAPI command.

Examples

- ATA_STATUS doesn't contain !BSY && DRDY && !DRQ while trying to issue a command.
- !BSY && !DRQ during PIO data transfer.
- DRQ on command completion.
- !BSY && ERR after CDB transfer starts but before the last byte of CDB is transferred. ATA/ATAPI standard states that "The device shall not terminate the PACKET command with an error before the last byte of the command packet has been written" in the error outputs description of PACKET command and the state diagram doesn't include such transitions.

In these cases, HSM is violated and not much information regarding the error can be acquired from STATUS or ERROR register. IOW, this error can be anything - driver bug, faulty device, controller and/or cable.

As HSM is violated, reset is necessary to restore known state. Reconfiguring transport for lower speed might be helpful too as transmission errors sometimes cause this kind of errors.

7.1.2. ATA/ATAPI device error (non-NCQ / non-CHECK CONDITION)

These are errors detected and reported by ATA/ATAPI devices indicating device problems. For this type of errors, STATUS and ERROR register values are valid and describe error condition. Note that some of ATA bus errors are detected by ATA/ATAPI devices and reported using the same mechanism as device errors. Those cases are described later in this section.

For ATA commands, this type of errors are indicated by !BSY && ERR during command execution and on completion.

For ATAPI commands,

- !BSY && ERR && ABRT right after issuing PACKET indicates that PACKET command is not supported and falls in this category.
- !BSY && ERR(==CHK) && !ABRT after the last byte of CDB is transferred indicates CHECK CONDITION and doesn't fall in this category.
- !BSY && ERR(==CHK) && ABRT after the last byte of CDB is transferred *probably* indicates CHECK CONDITION and doesn't fall in this category.

Of errors detected as above, the followings are not ATA/ATAPI device errors but ATA bus errors and should be handled according to Section 7.1.5.

CRC error during data transfer

This is indicated by ICRC bit in the ERROR register and means that corruption occurred during data transfer. Upto ATA/ATAPI-7, the standard specifies that this bit is only applicable to UDMA transfers but ATA/ATAPI-8 draft revision 1f says that the bit may be applicable to multiword DMA and PIO.

ABRT error during data transfer or on completion

Upto ATA/ATAPI-7, the standard specifies that ABRT could be set on ICRC errors and on cases where a device is not able to complete a command. Combined with the fact that MWDMA and PIO transfer errors aren't allowed to use ICRC bit upto ATA/ATAPI-7, it seems to imply that ABRT bit alone could indicate transfer errors.

However, ATA/ATAPI-8 draft revision 1f removes the part that ICRC errors can turn on ABRT. So, this is kind of gray area. Some heuristics are needed here.

ATA/ATAPI device errors can be further categorized as follows.

Media errors

This is indicated by UNC bit in the ERROR register. ATA devices reports UNC error only after certain number of retries cannot recover the data, so there's nothing much else to do other than notifying upper layer.

READ and WRITE commands report CHS or LBA of the first failed sector but ATA/ATAPI standard specifies that the amount of transferred data on error completion is indeterminate, so we cannot assume that sectors preceding the failed sector have been transferred and thus cannot complete those sectors successfully as SCSI does.

Media changed / media change requested error

<<TODO: fill here>>

Address error

This is indicated by IDNF bit in the ERROR register. Report to upper layer.

Other errors

This can be invalid command or parameter indicated by ABRT ERROR bit or some other error condition. Note that ABRT bit can indicate a lot of things including ICRC and Address errors. Heuristics needed.

Depending on commands, not all STATUS/ERROR bits are applicable. These non-applicable bits are marked with "na" in the output descriptions but upto ATA/ATAPI-7 no definition of "na" can be found. However, ATA/ATAPI-8 draft revision 1f describes "N/A" as follows.

3.2.3.3a N/A

A keyword the indicates a field has no defined value in this standard and should not be checked by the host or device. N/A fields should be cleared to zero.

So, it seems reasonable to assume that "na" bits are cleared to zero by devices and thus need no explicit masking.

7.1.3. ATAPI device CHECK CONDITION

ATAPI device CHECK CONDITION error is indicated by set CHK bit (ERR bit) in the STATUS register after the last byte of CDB is transferred for a PACKET command. For this kind of errors, sense data should be acquired to gather information regarding the errors. REQUEST SENSE packet command should be used to acquire sense data.

Once sense data is acquired, this type of errors can be handled similarly to other SCSI errors. Note that sense data may indicate ATA bus error (e.g. Sense Key 04h HARDWARE ERROR && ASC/ASCQ 47h/00h SCSI PARITY ERROR). In such cases, the error should be considered as an ATA bus error and handled according to Section 7.1.5.

7.1.4. ATA device error (NCQ)

NCQ command error is indicated by cleared BSY and set ERR bit during NCQ command phase (one or more NCQ commands outstanding). Although STATUS and ERROR registers will contain valid values describing the error, READ LOG EXT is required to clear the error condition, determine which command has failed and acquire more information.

READ LOG EXT Log Page 10h reports which tag has failed and taskfile register values describing the error. With this information the failed command can be handled as a normal ATA command error as in Section 7.1.2 and all other in-flight commands must be retried. Note that this retry should not be counted - it's likely that commands retried this way would have completed normally if it were not for the failed command.

Note that ATA bus errors can be reported as ATA device NCQ errors. This should be handled as described in Section 7.1.5.

If READ LOG EXT Log Page 10h fails or reports NQ, we're thoroughly screwed. This condition should be treated according to Section 7.1.1.

7.1.5. ATA bus error

ATA bus error means that data corruption occurred during transmission over ATA bus (SATA or PATA). This type of errors can be indicated by

- ICRC or ABRT error as described in Section 7.1.2.
- Controller-specific error completion with error information indicating transmission error.

- On some controllers, command timeout. In this case, there may be a mechanism to determine that the timeout is due to transmission error.
- Unknown/random errors, timeouts and all sorts of weirdities.

As described above, transmission errors can cause wide variety of symptoms ranging from device ICRC error to random device lockup, and, for many cases, there is no way to tell if an error condition is due to transmission error or not; therefore, it's necessary to employ some kind of heuristic when dealing with errors and timeouts. For example, encountering repetitive ABRT errors for known supported command is likely to indicate ATA bus error.

Once it's determined that ATA bus errors have possibly occurred, lowering ATA bus transmission speed is one of actions which may alleviate the problem. See Section 7.2.3 for more information.

7.1.6. PCI bus error

Data corruption or other failures during transmission over PCI (or other system bus). For standard BMDMA, this is indicated by Error bit in the BMDMA Status register. This type of errors must be logged as it indicates something is very wrong with the system. Resetting host controller is recommended.

7.1.7. Late completion

This occurs when timeout occurs and the timeout handler finds out that the timed out command has completed successfully or with error. This is usually caused by lost interrupts. This type of errors must be logged. Resetting host controller is recommended.

7.1.8. Unknown error (timeout)

This is when timeout occurs and the command is still processing or the host and device are in unknown state. When this occurs, HSM could be in any valid or invalid state. To bring the device to known state and make it forget about the timed out command, resetting is necessary. The timed out command may be retried.

Timeouts can also be caused by transmission errors. Refer to Section 7.1.5 for more details.

7.1.9. Hotplug and power management exceptions

<<TODO: fill here>>

7.2. EH recovery actions

This section discusses several important recovery actions.

7.2.1. Clearing error condition

Many controllers require its error registers to be cleared by error handler. Different controllers may have different requirements.

For SATA, it's strongly recommended to clear at least SError register during error handling.

7.2.2. Reset

During EH, resetting is necessary in the following cases.

- HSM is in unknown or invalid state
- HBA is in unknown or invalid state
- EH needs to make HBA/device forget about in-flight commands
- HBA/device behaves weirdly

Resetting during EH might be a good idea regardless of error condition to improve EH robustness. Whether to reset both or either one of HBA and device depends on situation but the following scheme is recommended.

- When it's known that HBA is in ready state but ATA/ATAPI device is in unknown state, reset only device.
- If HBA is in unknown state, reset both HBA and device.

HBA resetting is implementation specific. For a controller complying to taskfile/BMDMA PCI IDE, stopping active DMA transaction may be sufficient iff BMDMA state is the only HBA context. But even mostly taskfile/BMDMA PCI IDE complying controllers may have implementation specific requirements and mechanism to reset themselves. This must be addressed by specific drivers.

OTOH, ATA/ATAPI standard describes in detail ways to reset ATA/ATAPI devices.

PATA hardware reset

This is hardware initiated device reset signalled with asserted PATA RESET-signal. There is no standard way to initiate hardware reset from software although some hardware provides registers that allow driver to directly tweak the RESET- signal.

Software reset

This is achieved by turning CONTROL SRST bit on for at least 5us. Both PATA and SATA support it but, in case of SATA, this may require controller-specific support as the second Register FIS to clear SRST should be transmitted while BSY bit is still set. Note that on PATA, this resets both master and slave devices on a channel.

EXECUTE DEVICE DIAGNOSTIC command

Although ATA/ATAPI standard doesn't describe exactly, EDD implies some level of resetting, possibly similar level with software reset. Host-side EDD protocol can be handled with normal command processing and most SATA controllers should be able to handle EDD's just like other commands. As in software reset, EDD affects both devices on a PATA bus.

Although EDD does reset devices, this doesn't suit error handling as EDD cannot be issued while BSY is set and it's unclear how it will act when device is in unknown/weird state.

ATAPI DEVICE RESET command

This is very similar to software reset except that reset can be restricted to the selected device without affecting the other device sharing the cable.

SATA phy reset

This is the preferred way of resetting a SATA device. In effect, it's identical to PATA hardware reset. Note that this can be done with the standard SCR Control register. As such, it's usually easier to implement than software reset.

One more thing to consider when resetting devices is that resetting clears certain configuration parameters and they need to be set to their previous or newly adjusted values after reset.

Parameters affected are.

- CHS set up with INITIALIZE DEVICE PARAMETERS (seldomly used)
- Parameters set with SET FEATURES including transfer mode setting

- Block count set with SET MULTIPLE MODE
- Other parameters (SET MAX, MEDIA LOCK...)

ATA/ATAPI standard specifies that some parameters must be maintained across hardware or software reset, but doesn't strictly specify all of them. Always reconfiguring needed parameters after reset is required for robustness. Note that this also applies when resuming from deep sleep (power-off).

Also, ATA/ATAPI standard requires that IDENTIFY DEVICE / IDENTIFY PACKET DEVICE is issued after any configuration parameter is updated or a hardware reset and the result used for further operation. OS driver is required to implement revalidation mechanism to support this.

7.2.3. Reconfigure transport

For both PATA and SATA, a lot of corners are cut for cheap connectors, cables or controllers and it's quite common to see high transmission error rate. This can be mitigated by lowering transmission speed.

The following is a possible scheme Jeff Garzik suggested.

If more than \$N (3?) transmission errors happen in 15 minutes,

- if SATA, decrease SATA PHY speed. if speed cannot be decreased,
- decrease UDMA xfer speed. if at UDMA0, switch to PIO4,
- decrease PIO xfer speed. if at PIO3, complain, but continue

Chapter 8. ata_piix Internals

ich_pata_cable_detect

LINUX

Kernel Hackers Manual February 2009

Name

`ich_pata_cable_detect` — Probe host controller cable detect info

Synopsis

```
int ich_pata_cable_detect (struct ata_port * ap);
```

Arguments

ap

Port for which cable detect info is desired

Description

Read 80c cable indicator from ATA PCI device's PCI config register. This register is normally set by firmware (BIOS).

LOCKING

None (inherited from caller).

piix_pata_prereset

LINUX

Kernel Hackers Manual February 2009

Name

`piix_pata_prereset` — prereset for PATA host controller

Synopsis

```
int piix_pata_prereset (struct ata_link * link, unsigned long
deadline);
```

Arguments

link

Target link

deadline

deadline jiffies for the operation

LOCKING

None (inherited from caller).

piix_set_piomode

LINUX

Name

`piix_set_piomode` — Initialize host controller PATA PIO timings

Synopsis

```
void piix_set_piomode (struct ata_port * ap, struct ata_device  
* adev);
```

Arguments

ap

Port whose timings we are configuring

adev

um

Description

Set PIO mode for device, in host controller PCI config space.

LOCKING

None (inherited from caller).

do_pata_set_dmamode

LINUX

Name

`do_pata_set_dmamode` — Initialize host controller PATA PIO timings

Synopsis

```
void do_pata_set_dmamode (struct ata_port * ap, struct  
ata_device * adev, int isich);
```

Arguments

ap

Port whose timings we are configuring

adev

Drive in question

isich

set if the chip is an ICH device

Description

Set UDMA mode for device, in host controller PCI config space.

LOCKING

None (inherited from caller).

piix_set_dmamode

LINUX

Kernel Hackers Manual February 2009

Name

`piix_set_dmamode` — Initialize host controller PATA DMA timings

Synopsis

```
void piix_set_dmamode (struct ata_port * ap, struct ata_device  
* adev);
```

Arguments

ap

Port whose timings we are configuring

adev

um

Description

Set MW/UDMA mode for device, in host controller PCI config space.

LOCKING

None (inherited from caller).

ich_set_dmamode

LINUX

Kernel Hackers Manual February 2009

Name

`ich_set_dmamode` — Initialize host controller PATA DMA timings

Synopsis

```
void ich_set_dmamode (struct ata_port * ap, struct ata_device  
* adev);
```

Arguments

ap

Port whose timings we are configuring

adev

um

Description

Set MW/UDMA mode for device, in host controller PCI config space.

LOCKING

None (inherited from caller).

piix_check_450nx_errata

LINUX

Kernel Hackers Manual February 2009

Name

`piix_check_450nx_errata` — Check for problem 450NX setup

Synopsis

```
int piix_check_450nx_errata (struct pci_dev * ata_dev);
```

Arguments

ata_dev

the PCI device to check

Description

Check for the present of 450NX errata #19 and errata #25. If they are found return an error code so we can turn off DMA

piix_init_one

LINUX

Name

`piix_init_one` — Register PIIX ATA PCI device with kernel services

Synopsis

```
int piix_init_one (struct pci_dev * pdev, const struct
pci_device_id * ent);
```

Arguments

pdev

PCI device to register

ent

Entry in `piix_pci_tbl` matching with *pdev*

Description

Called from kernel PCI layer. We probe for combined mode (sigh), and then hand over control to libata, for it to do the rest.

LOCKING

Inherited from PCI layer (may sleep).

RETURNS

Zero on success, or -ERRNO value.

Chapter 9. sata_sil Internals

sil_set_mode

LINUX

Kernel Hackers Manual February 2009

Name

`sil_set_mode` — wrap `set_mode` functions

Synopsis

```
int sil_set_mode (struct ata_link * link, struct ata_device **  
r_failed);
```

Arguments

link

link to set up

r_failed

returned device when we fail

Description

Wrap the libata method for device setup as after the setup we need to inspect the results and do some configuration work

sil_dev_config

LINUX

Kernel Hackers Manual February 2009

Name

`sil_dev_config` — Apply device/host-specific errata fixups

Synopsis

```
void sil_dev_config (struct ata_device * dev);
```

Arguments

dev

Device to be examined

Description

After the IDENTIFY [PACKET] DEVICE step is complete, and a device is known to be present, this function is called. We apply two errata fixups which are specific to Silicon Image, a Seagate and a Maxtor fixup.

For certain Seagate devices, we must limit the maximum sectors to under 8K.

For certain Maxtor devices, we must not program the drive beyond udma5.

Both fixups are unfairly pessimistic. As soon as I get more information on these errata, I will create a more exhaustive list, and apply the fixups to only the specific devices/hosts/firmwares that need it.

20040111 - Seagate drives affected by the Mod15Write bug are blacklisted The Maxtor quirk is in the blacklist, but I'm keeping the original pessimistic fix for the following reasons... - There seems to be less info on it, only one device gleaned off the Windows driver, maybe only one is affected. More info would be greatly appreciated. - But then again UDMA5 is hardly anything to complain about

Chapter 10. Thanks

The bulk of the ATA knowledge comes thanks to long conversations with Andre Hedrick (www.linux-ide.org), and long hours pondering the ATA and SCSI specifications.

Thanks to Alan Cox for pointing out similarities between SATA and SCSI, and in general for motivation to hack on libata.

libata's device detection method, `ata_pio_devchk`, and in general all the early probing was based on extensive study of Hale Landis's probe/reset code in his ATADRVR driver (www.ata-atapi.com).

